




## Driver information interface (DII)\*

Consists of several displays that provide you with useful information.



### Main Displays


Press the display/information and ◀/▶ buttons to change main displays.



\*if equipped

## ■ Trip Computer

Use the TRIP knob to change the trip computer displays.



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>