

General operation

| Screen | Operation | Voice Command | | | | | | |
|--|--|-----------------|-----------------|-------------------------|-------------------|---------------------|----------------------|---------------------|
| | | US English | UK English | French | German | Dutch | Italian | Spanish |
| Any screen | Canceling the voice control mode | Cancel | Cancel | Annuler | Abbr. | Terug | Annulla | Cancelar |
| | Displays OEM Features screen *2 | OEM | OEM | OEM | OEM | OEM | OEM | OEM |
| | Switches to Mixed Media Search | Mixed Media | Mixed Media | Mixed Media | Mixed Media | Mixed Media | Mixed Media | Mixed Media |
| | Switches to DAB source *1 | DAB | DAB | DAB | DAB | DAB | DAB | DAB |
| | Switches to Wireless Link source | Wireless Link | Wireless Link | Wireless Link | Wireless Link | Wireless Link | Wireless Link | Wireless Link |
| | Switches to DVD source | DVD | DVD | DVD | DVD | DVD | DVD | DVD |
| | Displays Hands Free screen | Hands free | Hands free | Mains libres | Telefon | Handsfree | Vivavoce | Manos libres |
| | Switches to HD Radio source *2 | HD Radio | HD Radio | Radio HD | HD Radio | HD Radio | HD Radio | HD Radio |
| | Switches to iPod source | iPod | iPod | iPod | iPod | iPod | iPod | iPod |
| | Switches to Bluetooth Audio source | Bluetooth audio | Bluetooth audio | Audio Bluetooth | Bluetooth audio | Bluetooth audio | Audio Bluetooth | Audio Bluetooth |
| | Switches to SiriusXM source *2 | SiriusXM | SiriusXM | SiriusXM | SiriusXM | SiriusXM | SiriusXM | SiriusXM |
| | Switches to STANDBY source | Standby | Standby | Veille | Standby | Stand by | Attesa | En espera |
| | Switches to Cloud Storage source | Storage | Storage | Storage | Storage | Storage | Storage | Storage |
| | Displays the Top Menu screen | Top menu | Top menu | Menu sup | Hauptmenü | Hoofdmenu | Menu princ. | Menú superior |
| | Switches to Tuner source *1 | Tuner | Tuner | Tuner | Tuner | Tuner | Radio | Sintonizador |
| | Switches to USB source | USB | USB | USB | USB | USB | USB | USB |
| | Switches to Pandora source *2 | Pandora | Pandora | Pandora | Pandora | Pandora | Pandora | Pandora |
| | Switches the AV OUT source | AV out | AV out | sortie AV | AV out | AV uit | AV out | salida AV |
| | Displays the view from the Front View camera | Front camera | Front camera | Caméra avant | Frontkamera | Vooruitzicht camera | Telecamera frontale | Cámara delantera |
| | Displays the view from the Rear View camera | Rear camera | Rear camera | Caméra arrière | Rückfahrkamera | Camera achter | Retrocamera | Cámara trasera |
| | Displays Current Source Control screen | Control screen | Control screen | Écran de commande | Steuerbildschirm | Scherb besturen | Scherb. di controllo | Pantalla de control |
| | Searches the previous station/channel. | Seek down | Seek down | Rechercher vers le bas | Suche abwärts | Omlaag zoeken | Ricerca giù | Buscar anterior |
| | Searches the next station/channel. | Seek up | Seek up | Rechercher vers le haut | Suche aufwärts | Omhoog zoeken | Ricerca su | Buscar siguiente |
| | Searches the previous track/file. | Track down | Track down | Piste précédente | Titel abwärts | Track omlaag | Traccia giù | Pista anterior |
| | Searches the next track/file. | Track up | Track up | Piste suivante | Titel aufwärts | Track omhoog | Traccia su | Pista siguiente |
| | Switches to RSS Application | RSS | RSS | RSS | RSS | RSS | RSS | RSS |
| | Switches to Weather Application | Weather | Weather | Météo | Wetter | weer | Tempo | tiempo |
| | Switches to Facebook in SNS Application | Facebook | Facebook | Facebook | Facebook | Facebook | Facebook | Facebook |
| | Create a Facebook Status in SNS Application | Status | Status | Statut | Status | status | Stato | Estatus |
| | Switches to Twitter in SNS Application | Twitter | Twitter | Twitter | Twitter | Twitter | Twitter | Twitter |
| | Create a Tweet in SNS Application | Tweet | Tweet | Tweet | Twitter-Nachricht | Tweet | Tweet | Tweet |
| | Switches to Gmail in SNS Application | Mail | Mail | Message | Email | E-mail | Mail | Correo |
| | Posting the current place. | I'm Here | I'm Here | Je suis ici | Mein Standort | Ik ben hier | Ci sono | Estoy aquí |
| Posting the information about the song you are listening to. | I'm Listening | I'm Listening | J'écoute | Ich höre gerade | Ik luister | In ascolto | Escucho | |
| Switches to Schedule Application | Schedule | Schedule | Agenda | Kalender | Rooster | Programm | Programa | |

Displaying Voice Commands

The available voice commands depend on each screen and you can find them by pressing and holding the Push-To-Talk switch.

1 Press and hold the Push-To-Talk switch.



The list of operable voice commands appears. Pronounce a command.

Note

- About the voice command for navigation system, refer to the instruction manual of the navigation system.
- *1 DNN9230DAB only
- *2 DNN990HD only

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>