


KitchenAid®

6 QT. STAND MIXER

MODELS:

KL26M1XER5 (Empire Red)
KL26M1XOB5 (Onyx Black)
KL26M1XSL5 (Silver)


COLOR VARIATION PARTS



COLOR VARIATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing	4		Planetary	6		Column
	9705300	Empire Red		9708180	Empire Red		9705324	Empire Red
	9705296	Onyx Black		9708176	Onyx Black		9705320	Onyx Black
	9709571	Silver		9709575	Silver		9709585	Silver
2		Trim Band	5		Bowl Support and Pins	7		Base & Foot Assembly
	W10809493	Black		9705360	Empire Red		9705348	Empire Red
3		Lower Gearcase		9705356	Onyx Black		9705344	Onyx Black
	9706331	Empire Red		W10327840	Silver		9709588	Silver
	9706311	Onyx Black						
	9709578	Silver						


CASE, GEARING AND PLANETARY UNIT PARTS



CASE, GEARING AND PLANETARY UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing (Refer to Color Variation Parts Page)	12	16897	Bearing, Lower Center	25	W10247536	Motor, 120 Volt
2	9707983	Cap, Attachment Hub (Nickel)	13	9703339	Gear, Internal	26		Cord, Power
3		Band, Trim (Refer to Color Variation Parts Page)	14	3400814	Screw		W10325656	Black
4	9709125	Transmission Housing	15	9706247	Seal, Motor Shaft	27	8533910	Washer
5	9703338	Gear, Attachment Hub Level	16		Bearing	28		Planetary Assembly (Refer to Color Variation Parts Page)
6	9709511	Gasket, Transmission		W10170080	Front	29	W10323379	Washer, Fiber
7	9703680	Clip, Retaining		W10170081	Rear	30	9703438	Ring, Retaining
8	9703337	Gear, Bevel	17	9703445	Bearing, Thrust	31	9706090	Washer
9	9707223	Pin, Retaining	18	9709231	Gear, Worm	32	9707627	Gear, Pinion
10	9706529	Gear, Worm Follower	19	9706648	Control with Black Knob			
11		Lower Gearcase (Refer to Color Variation Parts Page)	20	9704677	Pin, Groove			
			21	3400200	Screw			
			22	3400617	Screw			
			23		Thumb Screw			
				9709194	Black			
			24	9708191	Shaft, Agitator			

BASE AND PEDESTAL UNIT PARTS



BASE AND PEDESTAL UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Base and Foot Assembly	15		Column Assembly
	W10862776	Use & Care Guide			(Refer to Color Variation Parts Page)			(Refer to Color Variation Parts Page)
2	3400200	Screw			(Refer to Color Variation Parts Page)	16	9703485	Beater, Flat (Burnished)
3	W10245251	Bowl, 6 Qt.	9	9708649	Foot	17	W10536041	Hook, Dough (Burnished)
4	240185	Pin, Retaining Bowl	10	9703307	Ring, Retaining	18	9706885	Arm, Bowl Lift
5	W10504114	Clip, Bowl Retainer	11	W10598835	Rod, Bowl Lift	19	9703491	Whip, Wire
6	3400018	Screw	12	9237	Spring, Lift Rod	20	9703426	Cam, Adjusting
7		Bowl Support	13	9703439	Washer	21	3400863	Screw
		(Refer to Color Variation Parts Page)	14	8533907	Nut	22	W10598836	Handle, Bowl Lift

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>