

**KitchenAid®**

**27" BUILT-IN ELECTRIC SINGLE WALL OVEN WITH CONVECTION**

**MODELS:**


KOSE507EBL02 (Black)

KOSE507EWH02 (White)

KOSE507ESS02 (Stainless)

KOSE507EBS02 (Black Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10669823	Blower	16	W10694466	Chassis, Cover Top
	W10643471	Guide, Use & Care	6	W10671226	Gasket, Rubber			Back 27"
	W10725670	Instructions, Installation	7	W10436434	Fuse, Thermal	17	W10728475	Gasket, Rubber
	W10888961	Instructions, Installation	8	7101P426-60	Screw			FOLLOWING PARTS
		(Black Stainless Models	9	7101P434-60	Screw			NOT ILLUSTRATED
		Only)	10	W10655463	Bracket, Blower (Left)		W10836586	Harness, Main
	W10351318	Instructions,		W10655462	Bracket, Blower (Right)		W10603909	Harness, Signal
	W10861943	Undercounter Install	11	4451758	Block, Foam		W10775068	Harness, Door Latch
		Sheet, Tech	12		Skin, Control Panel		W10562910	Harness, EOL
2		Assembly, Control Panel		W10588745	Black		4450800	Screw, Grounding
		(Includes Overlay)		W10588747	White		W10487999	Clip, Harness
	W10890587	Black		W10588741	Stainless		4452400	Strap, Lead Ground
	W10890583	White		W10861075	Black Stainless		4448664	Clamp, Conduit
	W10890586	Stainless		W10864102	Tray, Electronic		W10655464	Bracket, Harness
	W10890562	Black Stainless	13	W10864102	Tray, Electronic			
3	W10777215	Control (With Power	14	W10655465	Chassis, Back Divider			
		Supply)	15	W10318193	Chassis, Cover Top			
4	W10618105	Spacer, Lateral			Front 27"			

# OVEN PARTS




# OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10318196	Duct, Chassis Back
2	W10282946	Tube, Vent
3	W10616802	Receiver, Hinge
4	W10618102	Spacer, Base
5	W10618131	Latch, Motorized
6	W10813744	Chassis, Top
7	W10519866	Assembly, Oven Light
8	W10618101	Foot, Base
9	W10641572	Deflector, Blower
10	W10254050	Screw
11	W10282961	Gasket
12	W10616810	Cover, Vent Exhaust
13	W10318190	Side, Chassis
14	W10813734	Back, Chassis
15		Liner, Oven (Not Serviceable)
16	W10622170	Probe, Sensor

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10351278	Bumper & Screw
18	4449751	Thermostat (TOD)
19	W10282901	Base, Chassis
20		Assembly, Bottom Vent
	W10327375	Black
	W10506349	White
	W10351280	Stainless
	W10869573	Black Stainless
21	W10283008	Chassis, Bottom Duct
22		Trim, Bottom Vent
	W10351237	Black
	W10504025	White
	W10327378	Stainless
23	W10213759	Support, Air Channel
24	W10351308	Spacer, Chassis Bottom Duct
25	W10283037	Vent, Top 27"

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
26	8285593	Cover, Connector
27	7101P426-60	Screw
28	W10472386	Lens, Light
29		Cover, Side Trim
	W10344481	Black (Left)
	W10344480	Black (Right)
30	W10347649	Spacers, Front
31	W10472384	Bulb, Light
32	W10616809	Base, Vent Exhaust
33	W10607120	Screw
34	W10863234	Bracket, Side Cover (Left)
	W10863233	Bracket, Side Cover (Right)
		Following Parts Not Illustrated
	W10520716	Insulation, Wrap
	W10282945	Insulation, Back

# OVEN DOOR PARTS




# OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10347597	Assembly, Window Pack
2	W10284285	Spring, Door Glass Fixation
3	3196183	Screw
4		Badge
	W10518672	Grey
5	W10320793	Assembly, Liner
6	W10639067	Hinge, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7		Assembly, Door
	W10615246	Black
	W10615247	White
	W10615245	Stainless
	W10878437	Black Stainless
8		Assembly, Handle
	W10640874	Stainless
9	W10678525	Glass, Inner
10	W10284297	Bracket, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10480830	Screw
12	7101P426-60	Screw
13	7101P635-60	Screw (Black)
14	W10653954	Clip, Spring Metal
15	W10687815	Extension, Side Rail (Left)
	W10687814	Extension, Side Rail (Right)
16	W10669415	Shield, Door Liner

# INTERNAL OVEN PARTS





# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10764078	Element, Broil	9	W10631504	Nut, Acorn	15	W10696226	Jack, Meat Probe
2	W10554529	Rack, Oven	10	W10631503	Blade, Fan	16	9755547	Washer, Lock
3	W10318198	Tray, Hidden Bake	11	W10546519	Element, Convection	17	9755546	Nut, Hidden
4	7101P434-60	Screw	12	W10359277	Baffle, Bow Tie	18	W10554532	Rack, Sliding
5	7101P426-60	Screw		W10725944	Baffle, Bow Tie (Black Stainless Models Only)	19	9755542	Probe, Temperature
6	W10282957	Crossbar, Hidden Bake Tray	13	W10318164	Shield, Broil Element	20	7101P500-60	Screw
7	W10546517	Element, Bake	14	W10588738	Shield, Broil Front			
8	W10722667	Fan, Convection						

# OPTIONAL PARTS

## **PAIN, TOUCH-UP (1/2OZ.)**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

## **PAIN, SPRAY**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque
	350956	Almond
	350942	White Primer
	350938	Gray Primer

## **ADHESIVE**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic

## **ACCESSORIES**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10355016	Cleaner, Stainless Steel
	W10355010	Cleaner, Kitchen & Appliance
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>