


For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
(BLACK) (WHITE) (STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
 (BLACK) (WHITE) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT4452615	Installation Instructions Guide, Use & Care
	LIT4452614	English
	LIT4452618	French
	LIT4450786	Cook Guide Label
	LIT4451052	Guide–Easy Use M/W
	LIT8300541	Tech Sheet
		Easy Set Guide
	LIT4449264	English
	LIT4448687	French
	LIT3191638	Safer Cooking Tips
2		Trim, Side
	4452624	RH Black
	4452626	RH White
	4452556	RH Stainless
	4452625	LH Black
	4452627	LH White
	4452557	LH Stainless
3	4451605	Cap, Spacer
4		Rail, Side
	4452549	Right Side
	4452550	Left Side
5	4452559	Side, Chassis (R.H. & L.H.)
6	4452541	Base, Chassis
7		Trim, Bottom
	4452621	Black
	4452623	White
	4452569	Stainless
8	4452554	Chassis, Back
9	4449906	Extension Filler
10	3400832	Screw
11	4449809	Screw
12	4452492	Insulation–Grill
13	4452491	Insulation–Top
14	694091	Screw
15	4455471	Spacer, Rail (2)
16	4455476	Bracket
17	4455475	Bracket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
 (BLACK) (WHITE) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
1	4452604	Panel, Control Black
	4452605	White
	4451791	Stainless
2		Switch, Membrane
	4453028	Black
	4453029	White
	4453025	Stainless
3	4452248	Insulator, Board
4	4452249	Insulator, Board Support
5	4452260	Spacer, Foam
6	4452345	Insulator, Dielectric
7	4453377	Microcomputer
8	3400406	Screw
9	3400832	Screw
10	4451592	Filter, R.F.
11	4451632	Bracket, Filter

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE COMPARTMENT PARTS

For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
(BLACK) (WHITE) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
5	4452551	Support Rails Right Side
	4452552	Support Rails Left Side
11	4452548	Rear Channel
12	4449809	Screw
13	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
 (BLACK) (WHITE) (STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS


For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
(BLACK) (WHITE) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	30	4375279	Thermostat	54	4375439	Shield, Heat Right
3	4375252	Rubber Ring	31	4375423	Thermostat	55	4375422	Sensor, Temp.
4	4375038	Screw	32	4375281	Thermostat	56	4375420	Insulation
5	4375314	Air Duct, Magnetron	33	4375408	Q Tube Assembly	57	4375419	Duct, Heater
6	4375253	Support, Tube	34	4375438	Transformer	58	4375416	Washer
7	4375421	Plug, Ceramic	35	4375406	Ring, Turntable	59	4375417	Element, Heater
8	4375255	Bushing	36	4375407	Shaft, Turntable	60	4375418	Fan
9	4375256	Reflector	39		Bracket, Hinge	61	4375429	Motor, Fan
10	4375257	Chamber, Reflector		4375412	Left	62		Left-Threaded Nut Serviced With Motor Item 61
12	4375450	Duct, Inlet		4375413	Right			
13	4375316	Insulation, Switch	42	4375331	Plate, Grill			
14	4375322	Fan Wheel	43	4375332	Bracket			
15	4375317	Duct, Air	44	4375441	Fan Cap	63	4375430	Thermostat
16	4375415	Block, Slide	46		Switch Holder	64	4375431	Shield, Heat
17	4375248	Cover Plate, Upper		4375412	Left	65	4375432	Insulation
18	4375251	Screw		4375413	Right	66	4375433	Chamber, Heat
19	4375318	Lens, Lamp	47	4375258	Nut	67	4375437	Isolation Plate
20	4375319	Spring	48		Insulation	68	4375338	Cover Plate
21	4375320	Reflector		4375409	Left Side	71		Side Plate
22	4393900	Pan Handle		4375410	Right Side		4375341	Left
23	4452220	Rack	49	4375411	Plate, Side Bottom		4375342	Right
24	4393536	Crisp Plate				72	4375405	Turntable
25	4375436	Capacitor	50	4375425	Valve	73	4375346	Switch
26	4375424	Magnetron	51	4375428	Screw To Valve	74	4375347	Motor, Turntable
27	4375321	Fuse	52	4375427	Thermoactuator	75	4375348	Lamp
28	4375231	Block, Fuse	53	4375426	Air Bleed	76	4375349	Rectifier
29	4375278	Motor, Blower				77	4375435	Cable

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
(BLACK) (WHITE) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top
2	4448935	Baffle, Blower
3	4450920	Blower
4	4451789	Plate, Mounting
5	6610122	Transformer, (Lights)
6	4451634	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
11	4449868	Block, Terminal


Illus. No.	Part No.	DESCRIPTION
13	4450791	Vent-Cntrl Panel
14	4451597	Side, Control Top
	4451598	Right
	4451598	Left
15	4452244	Back, Control
16	4450551	Cover, Top Rear
17	4448664	Clamp
18	4450554	Cover, Top Front
19	4455038	Transformer-Cntrl Control

Illus. No.	Part No.	DESCRIPTION
20	4452247	Cover, Plate
21	4449809	Screw
22	3400016	Screw
23	112432	Nut
24	1180485	Screw
25	4451934	Suppressor
26	3400016	Screw
27	4450118	Nut
28	4450038	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
 (BLACK) (WHITE) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	4450946	Frame, Door
4	4449141	Bracket, Mounting Right Side
	4449142	Left Side
5	4449083	Filler, Side Right Side
	4449086	Left Side
6	4452502	Handle, Door Black
	4452503	White
	4452088	Stainless

Illus. No.	Part No.	DESCRIPTION
7	4452211	Glass, Outer Black
	4452789	White
	4452259	Stainless
8	4451055	Spacer (Stainless)
9	4452331	Bracket, Handle Retainer, Glass-Clip
10	4450863	Black
	4450864	White
	4451432	Stainless
11	4375339	Door, Plate
12	4375414	Frame, Inner

Illus. No.	Part No.	DESCRIPTION
13	4375330	Strap, Door
14	4375313	Screw
15	4375323	Hinge, Door Left
	4375324	Right
16	4451009	Spring, Torsion Bi/Wh Model
	4452396	Stainless Model
18	4449809	Screw
19	4449040	Screw
20	4450038	Screw
21	3196184	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: YKBMC140HB0, YKBMC140HW0, YKBMC140HS0
(BLACK) (WHITE) (STAINLESS)

Illus.	Part	
No.	No.	DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

FOLLOWING PARTS NOT ILLUSTRATED

482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

8300545 Harness, Main
4450831 Wire, Ground
4450800 Screw, Ground
4450950 Conduit, Combo
4448950 Screw, Install (4)
4452400 Lead, Ground Strap

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>