
peration Guide 5547/5563/5572 CASIO.

· Your watch may differ somewhat from the one shown in the illustration





To adjust the time setting

When the second hand is at 12 o'clock, pull the Crown out to Click 2.

Rotate the **Crown** to change the time setting.

Push the **Crown** back in on a time signal to resume timekeeping.

- Take care that you set the correct AM or PM time.
 When changing the time, move the minute hand four or five minutes past your final setting, and then back it up to the certification or were the control of the control of the control of the certification of the c to the setting you want

To change the day indicator setting

Pull the Crown out to Click 1. Rotate the Crown towards you to Push the Crown back in.

- The day indicator setting uses a 31-day month. Make adjustments for months of shorter lengths.
 Avoid changing the day indicator setting between the hours of 9 p.m. and 1 a.m. Otherwise, the day indicator may not change correctly at midnight. at midnight.


Crown Operations

Some water-resistant models (100 meters, 200 meters) have a some water-resistant modes (100 meters, 200 meters) have a screw-in crown. When you need to perform a crown operation, rotate it towards you to unscrew it. Then pull the crown out. Avoid applying undue force when pulling. The watch loses its water resistance while the crown is unscrewed. After performing a crown operation, fully screw the crown back in.



If your watch has a rotary bezel...

You can rotate the bezel to align its ▼ mark with the minute hand. Then you will be able to tell how much time has elapsed since aligning the ▼ mark.




Low Battery Alert

- The second hand will jump at two-second intervals to alert you when the charge is low. . Have the battery replaced as soon as possible after low battery alert is indicated
- Stopwatch operation is disabled during low battery alert
- If low battery alert occurs during a stopwatch operation, the stopwatch will automatically reset to all zeros and stop.

Using the Stopwatch

The stopwatch measures elapsed time in 1-second increments up to 9 minutes, 59 seconds.




Important!

Do not operate the stopwatch with the crown pulled out.

An elapsed time operation will stop automatically at the end of 10 minutes.

Correcting the 0 Positions of the Hands

Perform the following procedure if the stopwatch hands do not return to their 0 (zero) positions when you reset the stopwatch.



After all of the hands are the way you want, push the Crown back in.

Important!

Timekeeping stops while the crown is pulled out. Correct the current time setting after performing the above operation.

Specifications

Accuracy at normal temperature: ±20 seconds a month Stopwatch: Measuring Capacity: 9'59" (10 minutes)
Measuring Unit: 1 second
Measurements: Elapsed time; split time; two finishes

Other: Low battery alert

Battery: One silver oxide battery (Type: SR920SW)

Battery Life: Approximately 3 years

Specifications are subject to change without notice.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com