Dell Power Companion PW7015MC User's Guide

Regulatory model: PW7015M



Notes, Cautions, and Warnings

- **NOTE:** A NOTE indicates important information that helps you make better use of your power companion.
- △ CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.
- MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © 2015 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws.

DellTM and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

Contents

About your power companion 5
Product features
What's in the box
Features
Power companion
Charging your power companion 8
Charging your device
Charging your laptop
Charging your mobile devices
Checking the battery
Checking battery charge status
Checking battery health
Error status
Troubleshooting13
Common symptoms
Specifications14
General
Physical characteristics
Interfaces/Ports
Environmental

Statutory information 1	.5
Warranty	L 5
Limited warranty and return policies	15
For U.S. customers:	15
For European, Middle Eastern and African customers:	15
For non-U.S. customers:	15

About your power companion

Product features

The features of the Dell Power Companion PW7015MC include:

Portability

You could use your power companion to charge your Dell laptop or mobile devices while on-the-go.

Compatibility

Supports Dell dedicated PSID (Power Supply Identifier) protocol and select Dell power adapters.


Compliance

Suitable for devices compliant with USB battery charging specification, Revision 1.2 (BC1.2).

Compact design

Small in size and ideal to be placed in pockets/bags.

What's in the box












- 1 Power companion
- 3 Power-in cable
- 5 Ferrite cores (2)

- 2 Documents
- 4 Power-out cable

Features

Power companion




- 1 Power-in port (from laptop adapter)
- 3 Battery-status lights (5)
- 5 Power-out port (to laptop)
- 2 Power button/Battery-status button
- 4 USB-out ports (2)

Charging your power companion

MARNING: To avoid injury and damaging your device, only use the power adapter of your Dell computer.

Before first use, charge the power companion using the power adapter of your Dell computer.


- **NOTE:** It takes approximately 3 hours to fully charge the power companion.
- **NOTE:** You can charge your devices through the power companion while the power companion is getting charged.
- **NOTE:** The power adapter is not shipped with the power companion.



- 1. Connect one end of the power adapter of your Dell computer to the power-in cable. Then connect the power-in cable to the power-in port on the power companion.
- 2. Connect the power adapter of your Dell computer to an electrical outlet.
 - The battery-status light turns on (solid white) indicating the battery is getting charged. Refer to "Checking battery charge status" section for details.
 - The battery-status lights turn off when the battery is fully charged or when the power adapter is disconnected.
- **NOTE:** If the amber battery-status light lights up while the battery is charging, this indicates a charging error. Check if you are using the correct power adapter.
- **NOTE:** For more information on battery-status lights, see **"Checking battery charge status"**.

Charging your device

Charging your laptop




- 1. Connect one end of the power-out cable to the power-out port on the power companion.
- 2. Connect the other end of the power-out cable to the power-adapter port on your laptop.
- 3. Press the power button to start charging your laptop.



NOTE: The battery-status light blinks amber when the power companion battery is low.

Charging your mobile devices

Using the power companion, you can charge up to two portable devices simultaneously.



- 1. Connect one end of the USB cable to the USB port on the power companion.
- 2. Connect the other end of the USB cable to the charging port on your mobile device.
- **NOTE:** The USB cable is not shipped with the power companion.
- **NOTE:** The battery-status light blinks amber when the power companion battery is low.

Checking the battery

Checking battery charge status

You can check the battery-charge status by pressing the power button. The battery-status lights turn on indicating the battery-charge status of the power companion.

NOTE: The battery-status lights remain illuminated for 5 seconds after you release the power button.



Battery-status light	LED color & behavior	Battery capacity status
All 5 battery-status lights are off	Off	100%
All 5 battery-status lights are on O O O O	White (solid)	81% – 99%
1 st -4 th battery-status lights are on O O O O	White (solid)	61% - 80%
1 st -3 rd battery-status lights are on	White (solid)	41% - 60%
1 st -2 nd battery-status lights are on O O • • •	White (solid)	21% – 40%
1 st battery-status light is on	White (solid)	11% – 20%
1 st battery-status light blinks	Amber (blink)	1-10% (battery low state)

NOTE: All five battery-status lights turn off when the battery is fully charged.

Checking battery health

Battery health is a measurement reflecting the general condition of the battery. It indicates how much battery life remains before the power companion must be replaced.

NOTE: The units of SOH (State Of Health) are percentage (%) points.

A battery's SOH is 100% at the time of manufacture and will deteriorate gradually with usage.

Press and hold the power button for 5 seconds to turn on the power companion and check the battery health status.

Battery health status
81% – 100%
81% - 100%
61% - 80%
41% - 60%
21% - 40%
19/ 209/
1% – 20%

Error status

The type of error condition table is shown below.

Event	Battery-status light color & behavior	Status
All modes	One second flash ON/OFF interchangably on the $1^{\rm st}$ battery-status light (amber) and $2^{\rm nd}$ battery-status light (white)	Over temperature
PSID Fail or Daisy Chain	Solid amber	Error caused by using the wrong adapter.

Troubleshooting

Common symptoms

The following table contains information about common issues you might encounter and the possible solutions.

Common symptoms	Possible solutions
The power companion gets unusually hot when placed inside the pocket/bag.	 Unplug the power output cable immediately.
	 Take the power companion out of your pocket/bag immediately. Then let it cool down.
The power companion battery power gets drained too fast.	When connecting to a mobile device, close applications you are not using or set the device to airplane mode.
The battery-status light does not turn on.	 Check if the power companion is out of battery power. Charge the power companion.
	 If the problem persists, contact Dell or your dealer for technical assistance.

Specifications

General

Model number	PW7015MC (4-cell, 43Wh)
Supported input power adapters	Select Dell power adapters
Supported output	20 V, 2.25 A 5 V, 1.5 A
USB output	5 V, up to 2.1 A
LED	5 battery-status lights

Physical characteristics

Weight	293 g (0.65 lb)
Dimension (L x W x H)	121.5 x 78 x 21.5 mm
	(4.78 x 3.07 x 0.85in)
Cord length	300 mm (11.8in) (Power-in cable)
	650 mm (25.6in) (Power-out cable)

Interfaces/Ports

Input	One 7.4 mm barrel connector (female)
	One 4.5 mm barrel connector (female)
Output	One Dell proprietary connector (female)
	Two USB ports (battery charging 1.2 compliant)

Environmental

Temperature	Operating: 0°C to 40°C (32°F to 104°F) Storage: –20°C to 60°C (-4°F to 140°F)
Humidity	90% maximum relative humidity; non-condensing

Statutory information

Warranty

Limited warranty and return policies

Dell-branded products carry a 1-year limited hardware warranty.

For U.S. customers:

This purchase and your use of this product are subject to Dell's end user agreement, which you can find at http://www.dell.com/terms. This document contains a binding arbitration clause.

For European, Middle Eastern and African customers:

Dell-branded products that are sold and used are subject to applicable national consumer legal rights, the terms of any retailer sale agreement that you have entered into (which will apply between you and the retailer) and Dell's end user contract terms.

Dell may also provide an additional hardware warranty – full details of the Dell end user contract and warranty terms can be found by going to http://www.dell.com, selecting your country from the list at the bottom of the "home" page and then clicking the "terms and conditions" link for the end user terms or the "support" link for the warranty terms.

For non-U.S. customers:

Dell-branded products that are sold and used are subject to applicable national consumer legal rights, the terms of any retailer sale agreement that you have entered into (which will apply between you and the retailer) and Dell's warranty terms. Dell may also provide an additional hardware warranty – full details of Dell's warranty terms can be found by going to http://www.dell.com, selecting your country from the list at the bottom of the "home" page and then clicking the "terms and conditions" link or the "support" link for the warranty terms.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com