

5 / 8 Ports Desktop **Gigabit Ethernet Switches**



Thank you for purchasing Edimax gigabit switch. This high cost-efficiency switch complies with 10/100/1000-Base-TX standards is the best choice for Small office / Home office users. The ES-5500G/ES-5800G supports dynamic detection of cable length and dynamic adjustment of power required for the detected cable length for power savings. The switch also can detect link status for each ports. When the port is idle, the ES-5500G/ES-5800G will reduce power usage for the port. Easy install procedures allows any computer users to setup a network environment in very short time .

Product Package

- This package contains the following components:

 One Gigabit Switch

 Quick Installation Guide
- 5V 1A (ES-5500G) / 12V 1A (ES-5800G)
- Accessaries kit

If any item is missing or damaged, please contact your local resellers for service.

- Complies with the IEEE 802.3, IEEE 802.3u and IEEE 802.3ab standards.
- Smart Green Ethernet technology to reduce power consumption 30%-50%.
 Provides Store and Forward architecture, full wire speed filtering and forwarding rates.
- Supports Auto-MDI/MDI-X, full/half duplex modes and auto-negotiation.
- Supports flow control: back pressure for half-duplex, IEEE 802.3x for full-duplex mode.
 Supports Jumbo Frame in all speeds mode (10/100/1000Mbps).
- Automatic source address learning and aging, extensive front-panel diagnostic LEDs.

EDIMAX

Copyright © by Edimax Technology Co. LTD, all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or compute language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of this companion of the companion.

This company makes no representations or warranties, either expressed or implied, with respect to the contents hered and specifically disclaims any warranties, merchantability or finness for any programs prove decident following their purchase, the buyler of and to this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any pseens of each revision or changes.

The product you have purchased and the setup screen may appear slightly different from those shown in this Manual. The software and specifications are subject to change without notice. Please visit ow web site www.edime.com for the update. All rights reserved including all brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

Federal Communication Commission Interference Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful inference in a residential installation. This equipment generals, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment of eacuse harmful interference to radio or television reception, which can be determined by turning the equipment of sar on, the user is encouraged to by to correct the interference or mine of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is
- connected.

 4. Consult the dealer or an experienced radio technician for help.

whether the statement and the co-bested or operating in conjunction with any other and continued to the confidence of the FCD Males. Operation is subject to the following two conditions: (1) this device may not cause hamful interference, and (2) this device may not cause hamful interference, and (2) this device may not cause hamful interference, and (2) this device. Any changes or modifications not expressly approved by the party responsible for compliance could viold the authority to operative augment.

This is a Class A product. In a domestic environment, this product may cause radio interface, in which case the user may be required to take adequate measures.

Front Panel & Connectors





ES-5500G



ES-5800G

Fast Ethernet Switch LED Panel

LED	Color	Status	Description
PWR	Green	Lit	The switch is powered on
(Power)		Off	The switch is powered on
LNK/ACT (Link/Activity)	Green	Lit	A valid link is established
		Flash	Data packets received
		Off	No link is established

1. Operating Environment
This switching hub must be installed and operated within the limits of specified operating temperature 0"-40"C (32"- 104"F) and humidity 10% –90% (non-condensing).


 Do not place objects on top of the unit.
 Do not obstruct any vents at the sides of the unit.
 Do not obstruct any vents at the sides of the unit.
 Do not position the unit near any heating source such as heater, radiator, or direct exposure to sun.
 Prevent entering of water and moisture into the unit. If necessary, use dehumidifier to reduce humidity

2. Connecting to network devices The RJ-45 ports on the switch support Auto-MDI/MDI-X function which allows using straight-through or cross-over type cables to connect this switch to workstation or hub.

Connect one end of the network cable to the R.I-45 nort on the rear panel, and connect the other end of the network cable to the RJ-45 port on the network device. Follow the same procedure to connect all the RJ-45 ports of the switch.

The UTP network cables must comply with EIA/TIA 568 specifications and Category 5 standard for 100Mbps data transmission. Maximum length: using UTP cable, betw the switch and connected device is 100 meters (300ft).

Once the network cable is connected to both ends and the attached network device is powered on, the green LNK/ACT LED should be lit.



Connecting the power
 Connect the power adapter to the power connector on the rear panel of the unit; the green Power LED on the front panel should be lit.

Trouble Shooting

Power LED is not lit
 Check if the power cord is properly connected to the external power adapter and the power outlet. Make sure the DC power jack is firmly plugged into the power socket of

2. Link/Activity is not lit when connect to device

- . Check the power switch of the network device attached to the switch; make sure it is
- . Check the network cable; make sure it is properly connected to the switch and the
- . Check the network cable; make sure the UTP cables comply with EIA/TIA 568 and
- [1] Contact your dealer if problem persist.



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com