PERATOR'S MANUAL

650935-2

INCLUDING: SPECIFICATIONS, SERVICE KITS, GENERAL INFORMATION, TROUBLESHOOTING. INCLUDE MANUALS: 66266-X-B Lower Pump End (pn 97999-829), 67147-B Hydraulic Motor (pn 97999-1219) & S-632 General Information Manual (pn 97999-624)

REVISED:

(REV. C)

2.062 SQ." HYDRAULIC MOTOR 3.6:1 RATIO 6" STROKE

650935-X43-C **CHOP-CHECK PUMP SERIES**

CARBON STEEL



READ THIS MANUAL CAREFULLY BEFORE INSTALLING, OPERATING OR SERVICING THIS EQUIPMENT.

It is the responsibility of the employer to place this information in the hands of the operator. Keep for future reference.

SERVICE KITS

- Use only genuine ARO® replacement parts to assure compatible pressure rating and longest service life.
- 637449 for repair of hydraulic motor section.
- 637074-X43-B for repair of lower pump section. Refer to the chart on page 2 for description of -XXX options.


SPECIFICATIONS

Model Series (refer to option chart) 650935-X43-C **Type** Hydraulically Operated, Chop-Check **Hydraulic Motor** 67147-B **Motor Repair Kit** 637449 **Motor Size** 2.062 sq." (13.3 sq. cm) **Stroke** 6" (15.2 cm) Hydraulic Inlet (female) 3/8 - 18 N.P.T.F. - 2 Hydraulic Return (female) 1/2 - 14 N.P.T.F. - 2 Lower Pump End Series 66266-X43-B 637074-X43-B Material Inlet N/A Material Outlet (female) 1 - 11-1/2 N.P.T.F. - 1 Weight 62.1 lbs (28.2 kgs)

PERFORMANCE

Hydraulic Inlet Pressure Range . . . 50 - 1200 p.s.i. (3.4 - 83 bar) Fluid Pressure Range 180 - 4320 p.s.i. (12.4 - 297.9 bar) Required H-power @ 50 c.p.m. 3.2 @ 1200 (83 bar) Hydraulic flow required @ 50 c.p.m. 4.9 g.p.m. (18.5 l.p.m.) Maximum rec'd Cycles / Minute 50 Displacement In³ Per Cycle 6.959 Cycles Per Gallon 33.2 Flow @ 50 Cycles / Minute 1.5 g.p.m. (5.7 l.p.m.) Noise Level N/A Maximum Temperature Limit 130° F (54° C)

PUMP DATA




IMPORTANT

This is one of the four documents which support the pump. Replacement copies of these forms are available upon request. 650935-X-C Model Operator's Manual (pn 97999-836) S-632 General Information - Industrial Piston Pumps (pn 97999-624) ☐ 66266-X-B Lower Pump End Operator's Manual (pn 97999-829) 67147-B Hydraulic Motor Operator's Manual (pn 97999-1219)



PUMP OPTION DESCRIPTION CHART



PACKING MATERIAL (packings are upper and lower unless noted)

- 3 Glass filled Teflon
- UHMW-PE
- G UHMW-PE / Leather staggered
- P UHMW-PE / Teflon staggered (upper) / UHMW-PE (lower)
- R Teflon / UHMW-PE staggered (upper) / Teflon (lower)

SPRING ARRANGEMENT

4 Multiple wave spring

PLUNGER TYPE

3 Hardened stainless steel with hard chrome plating

GENERAL DESCRIPTION

⚠ WARNING HAZARDOUS PRESSURE. Do not exceed maximum operating pressure of 4320 p.s.i. (297.9 bar) at 1200 p.s.i. (82.8 bar) inlet hydraulic pressure.

PUMP RATIO X MAXIMUM PUMP INLET PRESSURE TO PUMP MOTOR = FLUID PRESSURE

Pump ratio is an expression of the relationship between the pump motor area and the lower pump end area. EXAMPLE: When 150 p.s.i. (10.3 bar) inlet pressure is supplied to the motor of a 5:1 ratio pump it will develop a maximum of 750 p.s.i. (52 bar) fluid pressure (at no flow) - as the fluid control is opened, the flow rate will increase as the motor cycle rate increases to keep up with the demand.

WARNING Refer to general information sheet for additional safety precautions and important information.

- The chop-check pumps are primarily designed for the pumping of heavy viscous material with or without fibrous content. The models can be used with a gravity feed single post lift as a topper type assembly or with a two post lift as a force feed type assembly. The lower pump is designed for easy priming and the double acting feature is standard in all ARO industrial pumps. Material is delivered to the pump discharge outlet on both the up and down stroke.
- The motor is connected to the lower pump end by a spacer section. This allows for lubrication of the upper packing gland and prevents motor contamination because of normal wear and eventual leakage through the material packing gland. Be sure the solvent cup is adequately filled with lubricant to protect the upper packings and insure longest service life.

TROUBLE SHOOTING

Pump problems can occur in either the hydraulic motor section or the lower pump end section, use these basic guidelines to help determine which section is affected.

If the pump will not cycle.

- Be certain to first check for non-pump problems including kinked, restrictive or plugged inlet / outlet hose or dispensing device. Depressurize the pump system and clean out any obstructions in the inlet / outlet material lines.
- Refer to the motor manual for trouble shooting if the pump does not cycle and / or hydraulic fluid leaks from the hydraulic motor.


If the pump cycles but does not deliver material.

Refer to the lower pump end manual for further trouble shooting.

PUMP CONNECTION - UPPER / LOWER

NOTE: All threads are right hand.

- 1. Lay the pump assembly on a workbench.
- Remove the three screws and washers from the three spacer rods (see figure 1).
- Pull the hydraulic motor from the lower pump end until motor piston rod is in the "down" position and lower pump end rod is in "up" position
- 4. Using e-ring pliers, slide the retaining ring up far enough to allow the sleeve to move upward and release the two connectors (see figure 2).



REASSEMBLY

- 1. Align the pump motor with the lower pump end.
- 2. Install the two connectors and retain with the sleeve, slide the retaining ring back into position.
- 3. Reinstall the spacer rods to the pump motor.
- Bring the motor and lower pump together and retain with the three screws and washers.

NOTE: If 93345-1 (3) spacer rods are removed from lower end to service lower end then torque evenly to 60 - 90 ft lbs (81.3 - 122.0 Nm).



PN 97999-836

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com