## Kodak



### AA/AAA Charger:

### Kodak Ni-MH Mini

Charger

#### **Operating Instructions**

4F8368

Model K630

Please read these instructions for safe operation.

 Charges one or two AA or AAA Ni-MH rechargeable batteries.

#### **Recommended Temperature Ranges for Use**

Ni-MH Batteries:	
Operating	32° - 122° F (0° - 50° C)
Charging (approx.)	32° - 104° F (0° - 40° C)
Storage	-4° - 86° F (-20° - 30° C)
Charger:	
Operating	32° - 104° F (0° - 40° C)
Storage	-4° - 140° F (-20° - 60° C)

Using the batteries outside the above temperatures may shorten battery life and decrease efficiency.

#### **Operating Instructions**

#### CHARGE INDICATOR LIGHTS

One or both lights are on (steady) during charging, depending on whether you are charging 1 or 2 batteries.

#### HOW TO CHARGE

1. Place 1 or 2 AA or AAA size batteries into the charger so that the + (positive) and - (negative) ends (terminals) of the batteries correspond to the same + and - markings in the charger.



- 2. Plug the charger into an electrical receptacle (outlet). The charge indicator lights are illuminated and battery charging begins. (NOTE: Do not insert or remove batteries during this charging process.) The charge indicator lights will remain on during charging. They will turn off only when the charger is unplugged or the batteries are removed.
- 3. The charging cycle time depends on battery type. See specification chart.

#### TIPS

- · For best performance, use only Kodak Ni-MH batteries.
- Charge the batteries before using (unless using pre-charged batteries).
- Do not use charged and discharged batteries together.

## IMPORTANT SAFETY INSTRUCTIONS—Save These Instructions

- DANGER—TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.
- ▲ CAUTION: Do not disassemble this product; there are no user-serviceable parts inside. Refer servicing to qualified service personnel.
- ▲ WARNING: Do not expose this product to liquid, moisture, or extreme temperatures. KODAK AC adapters and battery chargers are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards.

#### $\Delta Do not charge non-rechargeable batteries.$

 For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet. This battery charger is intended to be correctly oriented in a vertical or floor mount position.

#### Specifications

Model No.	K630		
Voltage	120 V AC		
Input	60 Hz 6 W		
Output	1.4 V DC		
LED Indication	ON steady — charging		
Battery/Charge	Ni-MH AA (2500 mAh)	18.5 hrs	
time (hours),	Ni-MH AA (2100 mAh)	15.5 hrs	
approximate	Ni-MH AA (1700 mAh)	13.5 hrs	
	Ni-MH AAA (900 mAh)	14 hrs	
	Ni-MH AAA (850 mAh)	13 hrs	
Dimensions	4.1" x 1.7" x 2.5"		
(L x W x H)	(105 x 44 x 63,5 mm)		
Weight	123 g +/- 10%		

Please dispose of this product in accordance with all applicable regulations. Disposal may be regulated. For disposal or recycling information, please contact your local authorities.

**Guarantee:** This battery charger and batteries are guaranteed against defects in material and workmanship for one year after date of purchase. Please call toll free: 1-800-820-5525 (between the hours of 9:00 a.m. and 5:00 p.m.).

#### Support

Internet: www.kodak.com/go/support www.kodak.com/go/contact

# Kodak

Made in China for EASTMAN KODAK COMPANY Rochester, New York 14650 U.S.A. © Eastman Kodak Company, 2008. MC/MR/TM: Kodak. 4F8368

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com