


This three way source selector switch allows easy and simple connection and selection of three separate audio receivers or amplifiers to a single pair of speakers. It may also be used to connect to three sets of speakers to a single receiver.

SPECIFICATION:
Screw terminal connectors accept up to 14 gauge wire
Rotary make-before brake switch
Color: white or ivory
Fits single gang junction box.



THREE WAY SOURCE SELECTOR SWITCH

ABC-1

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>