



TLX PS10 TLX PS12 Powered Subwoofer simple setup guide

thank you for choosing JBL. For over 50 years, JBL has been involved in every aspect of musical and film recording and reproduction, from live performances to monitoring the recordings you play in your home, car, or office.

We're confident that the **JBL loudspeaker** you have chosen will provide every note of enjoyment that you expected – and that when you think about purchasing additional audio equipment for your home, car, or office, you will once again choose JBL.

Please take a moment to complete the enclosed profile card. It enables us to keep you posted on our latest advancements, and helps us to better understand our customers and build products that meet your needs and expectations.

JBL Consumer Products

read first! Important Safety Precautions!

CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION Top revent electric shock, do not remove they roundingplug on the power cord, or use any plug or extension cordithat does not have a grounding plug provided. Make cortain that the AC outsit is properly grounded. Do not use an adapter plug with the product.



The lighting last other norther deputol, with an equident branch, is intended o deal therapert of the processor of university "Stangenous rollings with the product builting the of all states and states occurs builting the of all states and states occurs the books of processor.

The solar disposit rithin as epidemic hingle is intended to ded the user to the preserve its poster logar integral induces a comparing the appliance

1. Read Instructions. All the safety and operating instructions

should be read before the product is operated.

2. Retain Instructions. The safety and operating instructions should be retained for future reference. 3. Heed Warnings. All warnings on the product and in the operating instructions should be adhered to. 4. Follow Instructions. All operating and use instructions should be followed.

5. Water and Moisture. The product should not be used near water – for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, and the like.

6. Accessories. Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

7. Wall or Ceiling Mounting. The product should be mounted on a wall or ceiling only when and as recommended by the manufacturer. 8. Ventilation. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. 9. Heat. The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products that produce heat. If placed near an amplifier, check with the manufacturer for applicability. 10. Power Sources. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions. 11. Grounding or Polarization.

This product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

12. Power-Cord Protection. Powersupply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

13. Cleaning. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

 Nonuse Periods. The power cord of the product should be unplugged from the outlet when left unused for long periods of time.
 Lightning. For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges. 16. Overloading. Do not overload wall outlets, extension cords, or integral convenience receptacles, as this can result in a risk of fire or electric shock.

17. Object and Liquid Entry. Never push objects of any kind into this product through openings, as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

18. Damage Requiring Service.

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

a. The power-supply cord or the plug has been damaged; or

 b. Objects have fallen onto, or liquid has been spilled into, the product; or

c. The product has been exposed to rain or water; or

d. The product does not operate normally when following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation; or e. The product has been dropped, or the enclosure damage; or

f. The product does not appear to operate normally or exhibits a marked change in performance.
19. Attachments. Do not use attachments not recommended by the product manufacturer, as they


may cause hazards. 20. Replacement Parts. When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

21. Safety Check. Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

22. Servicing. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Part No. JBLULA 6/96


ONC. Placement




In front corner


two. Hookup

Line-Level - Stereo






Speaker-Level – Stereo



three. Operation

Mode	Procedure	LED Status
Off	Receiver/amplifier off	Red
0n	Receiver/amplifier on and playing program material	Green
Standby	Simply turn off your receiver/amplifier. The subwoofer will turn off after approximately five minutes. The subwoofer will turn on when your receiver/amplifier begins playing again.	Red

Volume



Crossover Frequency

The crossover frequency knob determines the highest frequency your subwoofer will reproduce. It allows a seamless transition from the subwoofer to the satellite speakers. Experiment with this adjustment to find the crossover frequency that sounds best with your speakers. When using the speaker level connections, the crossover adjustment will also limit the low frequencies being sent to your satellite speakers. This means that your satellites won't have to try and reproduce the information the subwoofer is playing.

Troubleshooting

If you used the high-level (speaker) inputs and there is no sound from any of the speakers, check the following:

Receiver/amplifier is on and a source is playing.
Powered subwoofer is plugged in.

• Check all wires and connections between receiver/ amplifier and speakers. Make sure all wires are connected. Make sure none of the speaker wires are frayed, cut, or punctured.

• Review proper operation of your receiver/amplifier.

If there is low bass output, check the following:

• Make sure the connections to the left and right "Speaker Inputs" have the correct polarity (+ and –).

• Make sure that the subwoofer is plugged into an active electrical outlet.

• Powered subwoofer is plugged in.

• Adjust the crossover point.

If you used the line-level inputs and there is no sound from the subwoofer, check the following:

 Receiver/amplifier is on and a source is playing.

• Powered subwoofer is plugged in.

• Check all wires and connections between receiver/ amplifier and subwoofer. Make sure all wires are connected. Make sure none of the wires are frayed, cut, or punctured.

• Review proper operation of your receiver/amplifier.

Specifications

-	PS10	PS12
Amplifier Power (RMS)	100 watts	120 watts
Driver	10-inch High-Polymer Laminate	12-inch High-Polymer Laminate
Inputs	Line-Level & Speaker-Level	Line-Level & Speaker-Level
Outputs*	High-Level w/High-Pass Filter at 180Hz	High-Level w/High-Pass Filter at 180Hz
Crossover Frequency (continuosly variable)	50–150Hz	50–150Hz
Frequency Response(-6dB)	30Hz to (90–150Hz)	23Hz to (90–150Hz)
Dimensions (H x W x D)	17 x 13 x 16 3/4 inches 432 x 356 x 426mm	19 3/4 x 15 x 16 3/4 inches 502 x 381 x 426mm
Weight	36 lbs/16.4 kg	43 lbs/19.5 kg
Shipping Weight	42 lbs/19 kg	49 lbs/22.3 kg

0040

*High-level (speaker) outputs are active only if high-level inputs are used.

0040

Occasional refinements may be made to existing products without notice, but will always meet or exceed original specifications unless otherwise stated.



JBL Consumer Products 80 Crossways Park West, Woodbury, NY 11797 8500 Balboa Boulevard, Northridge, CA 91329 1-800-336-4JBL (4525) (USA only) www.jbl.com

© 1997 JBL, Incorporated. JBL is a registered trademark of JBL, Incorporated. 5/97 **③** Part No. TLXPS10/12

A Harman International Company

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com