
98665



Flat Panel Pop-Up Camera User's Manual



www.jascoproducts.com

For technical support contact Jasco Products at 1-800-654-8483

Table of Contents

Cautions	2
System Requirements.....	3
Maintenance Care and Storage	3
Contents.....	3
Getting to Know Your Flat Panel Pop-Up Camera	4
Installation	4
Mounting Your Camera.....	6
Arcsoft Webcam Companion	6
Troubleshooting.....	7
2 Year Limited Warranty.....	8
FCC Statement.....	9

Cautions - Read Before Using Your Flat Panel Pop-Up Camera

1. You must install the camera driver **BEFORE** connecting the camera to your computer.
2. Please read this user's manual before operating your Flat Panel Pop-Up Camera.
3. Do not leave camera connected to the USB port if camera is not going to be used for a long period of time. This can adversely affect the picture quality.

System Requirements

1. Operating System - Microsoft® Windows® ME and above
2. CD drive
3. USB port

Maintenance Care and Storage


1. Do not use or store the camera in high humidity and extreme high/low temperature.
2. Do not touch the lens with your fingers.
3. Do not drop the camera or get the camera wet.
4. Do not try to repair the camera.
5. To clean the camera, use a dry cloth. Do not use organic solvents, such as alcohol etc. to clean the camera.
6. Store the camera in a dry and clean place

Contents

1. Flat Panel Pop-Up Camera with foldable stand
2. Laptop clip
3. CD with driver and Arcsoft Webcam Companion.
4. Instruction manuals
5. Retractable USB cable

Getting to Know Your Flat Panel Pop-Up Camera

Note: You must install the camera driver **BEFORE** connecting the camera to your computer.



Installation

Please note that you must install the camera drivers **BEFORE** you connect the camera to the USB port of your computer.

1. You must install all relevant updates, service packs, and patches for your operating system. These are available on Microsoft's® website under "Resources". Use the "Windows Update" link. (www.microsoft.com).
2. Insert the included 98665 Flat Panel Pop-Up Camera CD into the CD Rom Drive. (The CD should auto load).
3. If CD does not auto load, follow these steps:
 - a. Double click on My Computer
 - b. Double click on the CD icon on the CD drive
 - c. Double click on setup.exe

-
4. The installation menu will come up. Select 98665 Flat Panel Pop-Up Camera Driver.
 5. Follow the installation wizard instructions.
 6. It may be necessary to have your Windows installation disk available to install any additional windows drivers onto your computer. You will receive a prompt if this is necessary.
 7. (Optional) On the installation menu, select ArcSoft Webcam Companion. Follow the on screen instructions to install the photo and video editing software. DirectX® may install as well. You may need to reboot your computer.
 8. (Optional) Select User's Manuals to open a PDF version of the 98665 Instruction Manual in either English or Spanish. You will need Adobe Reader to open the user's manuals.
 9. (Optional) To download Adobe® Reader® select Adobe Reader from the menu screen and follow the instructions. You may need to reboot your computer.
 10. When you have installed the driver, and any optional software you want to install, select Exit.
 11. Remove the warning label from the USB plug of your camera.
 12. After your computer reboots, plug your camera's USB plug into the USB port of your computer.
 13. Open ArcSoft WebCam Companion and enjoy!

Mounting your camera

The camera may be used on a stable flat surface, such as a desk, or attached to a laptop screen using the laptop clip. To attach the camera to your laptop follow the instructions below:

1. Unplug the mini USB cable from the base of the Flat Panel Pop-Up Camera.
2. Detach the top ring of the Flat Panel Pop-Up Camera from the bottom three rings.
3. Plug the mini USB cable into the single ring that is now separate from the base.
4. Clip the new laptop webcam onto your laptop screen.



ArcSoft WebCam Companion™

Arcsoft WebCam Companion is a tool that will allow your GE webcam to function at its full capability. After it is installed according to the instructions on page 5, you may open the application by double clicking on the icon on your desktop. You should see an introduction screen like the one below.



At this screen you can navigate through the software program. Each of the four icons in the picture above will take you to a different function. Click on one of the icons and discover the world of ArcSoft WebCam Companion. For detailed instructions, click on the help tab.

Troubleshooting

1. Camera will not turn on
 - Make sure the camera is plugged into the USB port correctly
 - Make sure your USB port is functioning properly. You may need to install updates, service packs, or patches for your operating system from Microsoft's® website, www.microsoft.com. Go to "Windows Update" under Resources.
2. Uninstall the Flat Panel Pop-Up Camera driver
 - Close all open applications.
 - Go to the Start Menu → (Settings in some operating systems) → Control Panel → Add/Remove Programs
 - Select "98665 Flat Panel Pop-Up Camera"
 - Select "Remove", then "OK" to uninstall the driver.
 - Select "Yes, I want to restart my computer", then "Finish".
 - Your computer will now reboot.
3. "Can't detect camera", "Can't find VFW driver", or "Can't find camera driver" errors
 - Close all open applications.
 - Unplug the Flat Panel Pop-Up Camera from your computer.

-
- Uninstall the Flat Panel Pop-Up Camera software according to the directions above, then reboot your computer.
 - Re-install the Flat Panel Pop-Up Camera driver according to the installation directions, then reboot your computer.
 - Plug in your Flat Panel Pop-UpCamera.

**Microsoft and Arcsoft may update their software at any time.

TWO YEAR LIMITED WARRANTY

Jasco Products Company warrants this product to be free from manufacturing defects for a period of two years from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company
10 E. Memorial
Oklahoma City, OK 73114

FCC Statement

Notice: Federal Communications Commission (FCC) requirements, Part 15

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes of modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Distributed for GE
by Jasco Products Company
10 E. Memorial, Oklahoma City, OK 73114
www.jascoproducts.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>