



Speaker System 2.1

Instruction Manual

98903



www.jascoproducts.com

1. Introduction

The GE 2.1 Speaker System provides high quality stereo sound for a variety of applications: listen to CD's or MP3's from your computer or portable audio device, realistic sound for gaming, or sound for your multimedia presentations. The high-power subwoofer is enclosed in wood for deep, rich bass resonance. Each satellite speaker features high fidelity sound previously unavailable in computer speakers. The GE 2.1 Speaker system is acoustically balanced for high quality digital audio sound reproduction that goes beyond comprehension for your listening pleasure.

2. Package Contents

- 8 Watt (RMS) Wood Subwoofer
- Two 3 Watt (RMS) Satellite Speakers
- UL Listed AC/DC Power Adapter
- 3.5mm Stereo Cable
- Instruction Manual

3. Features

- High-power wood subwoofer
- Two full-range satellites
- Balanced acoustics to reduce harmonic distortion
- Easy Access Control Panel on Subwoofer
- On/Off Control Knob
- Main Volume Control Knob
- Bass Level Control Knob
- Power on indicator blue LED
- Magnetically shielded to reduce interference

4. System Requirements

- Compatible with Windows® or Mac®
- Standard sound card with 3.5mm output jack
- Most CD, MP3, MP4 players with 3.5 mm headphone jack.

5. Installation

Read and follow all instructions carefully. Shut down your computer and turn off power to speakers before installation. Failure to do so could result in injury or equipment damage.

- Connect the satellite speaker cables to the appropriate satellite speaker connectors on the back of the subwoofer. Make sure to connect the right speaker to the red right (“R”) jack and the left speaker to the white left (“L”) jack for accurate stereo sound.
- Connect your speakers to your...

Computer

Plug one end of the 3.5mm stereo cable into the “Line In” input jack on the back of the subwoofer. Plug the other end of the 3.5mm stereo cable into the output jack on your computer sound card. (The cable end is color coded to match the green color of the output jack on most sound cards.)

Portable Audio Device

Plug one end of the 3.5mm stereo cable into the “Line In” input jack on the back of the subwoofer. Plug the other end of the 3.5mm stereo cable into the headset jack on your audio device.

DVD Player, TV, etc

You will need a 3.5mm plug to dual RCA plug converter cable. Plug the 3.5mm plug of the converter cable into the “Line In” input jack on the back of the subwoofer. Then plug the dual RCA plug of the converter cable into the dual RCA audio output jack on your DVD player, TV, etc.

This cable (model 97691) can be purchased on our website:

<http://www.jascoproducts.com/>

Gaming Console

You will need a 3.5mm plug to dual RCA jack converter cable. Plug the 3.5mm plug of the converter cable into the “Line In” input jack on the back of the subwoofer. Then plug the dual RCA plug of your game box into the dual RCA audio output jack of the converter cable.

This cable (model 97691) can be purchased on our website:

<http://www.jascoproducts.com/>

- Turn the volume control and the bass level knob to the lowest setting on your speakers (counter-clockwise) before connecting the power to your 2.1 Speakers. Also turn the volume to the lowest setting on each device connected to you speakers such as your computer, multimedia player, television, etc.
- Connect the power adapter to the “AC IN” jack on the back of the subwoofer.
- Plug the power adapter into a standard AC electrical outlet. A GE surge protector is recommended to protect your new 2.1 Speakers.
- Turn the power knob on the subwoofer clockwise to switch on the power. The blue LED will illuminate when the power is switched on.
- Turn on your audio source: Begin playing music on your computer or portable audio device; make sure your television is on; start a game on your gaming console.
- Turn up the volume on each device connected to your speakers such as your computer, multimedia player, television, etc.
- Adjust the volume and bass level on your speakers to a comfortable listening level.


6. Headphones

To use headphones, set the volume to its lowest level before inserting the headphone plug into the headphone jack on the back of the subwoofer. Adjust the volume as needed.

7. One Year Limited Warranty

Jasco Products Company warrants this product to be free from manufacturing defects for a period of one year from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other product that may be used with this unit. This warranty is in lieu of all other warranties express or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to:

Jasco Products Company
10 East Memorial Road
Oklahoma City, OK 73114

 is a trademark of the General Electric Company and is used under license to Jasco Products Company LLC, 10 E. Memorial Road, Oklahoma City, OK 73114.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>