

OWNER'S MANUAL FOR KENMORE HEPA AIR CLEANER MODEL 152.85244



INFO - LINE:

After reading this manual, if you have any questions or comments on your Kenmore Air Cleaner, call 1-888-277-2810

SafetyOperationWarrantyParts

To order replacement filters by phone, call toll free: 1 (800) 366-7278 7 AM to 7 PM 7 days a week

Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.

Download from Www.Somanuals.com. All Manuals Search And Download.

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this product. Save these instructions for easy reference. When using electrical appliances, basic precautions should always be followed to reduce breakage, risk of fire, electric shock and injury to persons including the following:

- Read all instructions before operating the air cleaner.
- Place the air cleaner where it is not easily knocked over by persons in the household.
- · ALWAYS unplug air cleaner when not in use.
- DO NOT use any product with a damaged cord or plug, or if product malfunctions, is dropped or damaged in any manner.
- · Keep the power cord away from heated surfaces.
- DO NOT use air cleaner outdoors.
- NEVER use the air cleaner unless it is fully assembled.
- DO NOT run power cord under carpets and DO NOT cover with throw rugs. Arrange cord so it will not be tripped over.
- DO NOT use air cleaner where combustible gases or vapors are present.
- **DO NOT** expose the air cleaner to rain, or use near water, in a bathroom, laundry area or other damp locations.
- To disconnect air cleaner, first turn speed dial to OFF position and remove plug from outlet.
- DO NOT allow foreign objects to enter ventilation or exhaust opening, as this may cause electric shock or damage to the air cleaner.
 DO NOT block air outlets or intakes.
- Place air cleaner near a power outlet, and avoid using an extension cord.
- The air cleaner has a polarized plug (one blade is wider than the other). To reduce the risk of shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet. **DO NOT** try to alter the plug in any way.
- A loose fit between the plug and the AC outlet (receptacle) may cause overheating and distortion of the plug. Contact a qualified electrician to replace loose or worn receptacles.
- DO NOT sit, stand or place heavy objects on the air cleaner.
- ALWAYS disconnect power supply before servicing.

⚠ WARNING: To reduce the risk of fire or electric shock, DO NOT use this product with any solid-state speed control device.

ONE YEAR FULL WARRANTY ON KENMORE AIR CLEANER

If this air cleaner fails due to a defect in material or workmanship within one year from the date of purchase, return it to your nearest Sears Parts & Repair Center to have it repaired free of charge. Free repair does not include replacing the pre-filter or HEPA filter, which are expendable parts that can wear out from normal use before one year expires.

If repair is not possible, at your option Sears will replace this product or refund its full purchase price.


This warranty is void if this product is used for commercial or rental purposes.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears, Roebuck and Co., Dept. 817WA, Hoffman Estates, IL 60179

INTRODUCTION

Congratulations on your choice of the Kenmore HEPA Air Cleaner. We highly recommend that you operate the Air Cleaner 24 hours a day, because indoor air can be quickly contaminated by activity or objects in a room and infiltration of outside air. Portable air cleaners are much more effective in rooms where all doors and windows are closed.



HOW IT WORKS

This Air Cleaner is equipped with a HEPA (High Efficiency Particulate Arrestor) filter. Room air is drawn into the Air Cleaner through the Air Intake Grille and passes through the HEPA filter. The filtered air is released from the top of the unit and is dispersed upwards into the room.

The Air Cleaner has three operating speeds: HI, MED and LO. The indicator light is "ON" when the Air Cleaner is operating.

Your Air Cleaner has an ionizer with a red light indicating when it is turned "ON".

Use of ionizer boosts cleaning efficiency and revitalizes stale air.

SET UP

Your Air Cleaner was thoroughly inspected and tested at the factory prior to packaging. Visually inspect it upon removal from its box. Remove and discard any packaging material. Return the unit if it shows any signs of damage or mishandling.

Adjust the filter change wheel to properly indicate when the next filter change is necessary.

ELECTRICAL HOOKUP

Plug the Air Cleaner into a polarized 120-Volt AC wall outlet.

WARNING: To avoid the risk of fire or electric shock hazard, the Air Cleaner should ONLY be plugged into a polarized 120-Volt AC outlet.

OPERATION

CAUTION! NEVER operate the Air Cleaner without the HEPA filter properly installed. Permanent motor damage could result.

Each time you start the Air Cleaner, it is a good idea to run it at HI speed for a few seconds for fast, initial cleaning. Then set to MED or LO as desired.

OPERATION cont.

• HI

• MED

• LO Nighttime Use

Fast Initial Cleaning Normal Cleaning Quieter Operation

 On/Off lonizer Use for fast initial cleaning Operation

 When the ionizer is activated it helps to further clean and freshen the air by removing small airborne particles. When using ionizer, be sure to place air cleaner about one foot away from the walls. This will help keep airborne dust particles from depositing on walls.


FILTER CHANGE SCHEDULE

 HEPA Filter: The usable lifetime of the HEPA filter is 1 - 2 years, depending upon the level of the room's air contaminants and the frequency of use. The HEPA filter will turn medium brown and air volume will begin to decrease dramatically when the filter needs to be changed. You should have a spare filter available for later replacement.

FILTER REPLACEMENT

This HEPA filter is specially designed for easy replacement to provide maximum performance. THE HEPA FILTER IS NOT WASHABLE.

- 1. Turn the air cleaner OFF and unplug it from the power outlet.
- 2. Carefully lay the unit down on a flat surface with the Front Grille facing up.
- 3. Gently push in on Release Buttons on both sides of the unit, pull Front Grille out and away.
- 4. Remove and discard used HEPA filter.
- 5. Remove any plastic protective wrapping and packaging from the new HEPA filter.
- 6. Set new HEPA filter into the air cleaner.
- 7. Install the Front Grille by engaging its tabs into the bottom slots on the unit. Then swing grille up and gently push in top to snap into place.
- 8. Turn the Air Cleaner upright and plug it into an outlet for operation.



CLEANING THE UNIT

WARNING: To avoid serious injury from electric shock ALWAYS turn the Air Cleaner OFF and disconnect the plug from the outlet BEFORE cleaning.

- 1. Turn Air Cleaner OFF and unplug from outlet.
- Clean unit with a moistened soft cloth only. DO NOT pour or splash water on the unit or use any abrasive-type cleaner on it. Clean all external surfaces, especially the air intake grilles and air outlet.
- DO NOT attempt to clean the HEPA filter; it IS NOT washable and washing will damage it.
- 4. Reposition Air Cleaner plug into power outlet and turn ON.

STORAGE

If you store your Air Cleaner for more than 30 days you should:

- 1. Remove the HEPA filter from the unit.
- 2. Wrap the HEPA filter in an air-tight plastic bag or plastic wrap. Be sure that the filter is totally sealed to protect it from its storage environment.
- 3. **DO NOT** put the plastic-wrapped HEPA filter back into the Air Cleaner.
- 4. To restore the Air Cleaner to service:
 - Unwrap the HEPA filter.
 - Install filter assembly in the air cleaner. See "Filter Replacement" section for proper installation.

TECHNICAL SPECIFICATIONS

MODEL	85244
Length	12 in. (30.5cm)
Width	6,5in. (16.5cm)
Height	14 in. (36.5cm)
Weight	7.2 lbs. (3.3kg)
Input Voltage	120 volts AC, 60 Hz

REPLACEMENT PARTS

MODEL	85244
Filter	83159

CUSTOMER ASSISTANCE LINE

If you experience a problem, please see the warranty for information. **DO NOT** attempt to repair this unit yourself. Doing so will void your warranty, and could cause serious personal injury to yourself, or damage the Air Cleaner.

If you have any questions concerning this appliance, please call toll free: 1-888-277-2810

Monday - Friday 8:30 A.M. to 5:00 P.M. CST

HOW TO ORDER REPLACEMENT PARTS

To order replacement parts by phone, call toll free 1-800-366-7278

7 A.M. - 7 P.M. 7 days a week

Get it fixed, at your home or ours!

Your Home

For repair – in your home – of all major brand appliances, lawn and garden equipment, or heating and cooling systems,

no matter who made it, no matter who sold it!

For the replacement parts, accessories and owner's manuals that you need to do-it-yourself. For Sears professional installation of home appliances and items like garage door openers and water heaters.

1-800-4 -MY-HOME® (1-800-469-4663) www.sears.com Anytime, day or night (U.S.A. and Canada) www.sears.ca

Our Home

For repair of carry-in items like vacuums, lawn equipment, and electronics, call or go on-line for the location of your nearest

Sears Parts & Repair Center.

1-800-488-1222

Call anytime, day or night (U.S.A. only)

www.sears.com

To purchase a protection agreement (U.S.A.) or maintenance agreement (Canada) on a product serviced by Sears:

1-800-827-6655 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación a domicilio, y para ordenar piezas: 1-888-SU-HOGARSM (1-888-784-6427) Au Canada pour service en français: 1-800-LE-FOYER^{MC} (1-800-533-6937) www.sears.ca



® Registered Trademerk / TM Trademark / SM Service Mark of Sears, Roebuck and Co.
® Marca Registrada / TM Marca de Fábrica / SM Marca de Servicio de Sears, Roebuck and Co.
M Marque de commerce / MD Marque déposée de Sears, Roebuck and Co.

© Sears, Roebuck and Co.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com