Technical Support

Technical support is available to all registered users of Kensington products. Technical Support contact information can be found on the back page of this manual.

Web Support

You may find the answer to your problem in the Frequently Asked Questions (FAQ) section of the Support area on the Kensington Website: www.support.kensington.com.

Telephone Support

There is no charge for technical support except long-distance charges where applicable. Please visit **www.kensington.com** for telephone support hours.

Please note the following when calling support:

- Call from a phone where you have access to your device
- · Be prepared to provide the following information:
 - Name, address, and telephone number
 - The name of the Kensington product
 - Make and model of your computer
 - System software and version
 - Symptoms of the problem and what led to them

CE DECLARATION OF CONFORMITY

Kensington declares that this product is in compliance with the essential requirements and other relevant provisions of applicable EC directives.

For Europe, a copy of the *Declaration of Conformity* for this product may be obtained by clicking on the "Compliance Documentation" link at **www.support.kensington.com**.

SAFETY AND USAGE GUIDELINES

- In the absence of proper operation and if customer-initiated troubleshooting is unsuccessful, remove adapter from the AC mains and contact Kensington technical support: www.kensington.com.
- Do not disassemble product or expose it to liquid, humidity, moisture, or temperatures outside the specified operating ranges of 0° C (32° F) to 40° C (104° F).
- If your product is exposed to out-of-range temperatures, remove adapter from the AC mains and allow temperature to return to the normal operating range.

Kensington and the ACCO name and design are registered trademarks of ACCO Brands. The Kensington Promise is a service mark of ACCO Brands. All other registered and unregistered trademarks are the property of their respective owners.

© 2009 Kensington Computer Products Group, a division of ACCO Brands. Any unauthorized copying, duplicating, or other reproduction of the contents hereof is prohibited without written consent from Kensington Computer Products Group. All rights reserved. 10/09

Technical Support


United States 1 800 535 4242 International Toll +31 53 484 913






International Travel Plug Adapter with USB Charger

Instruction Guide





Contents


- A International Travel Plug Adapter
- USB Adapter Cap
- C Wall Adapter Cap
- D Extra Fuse
- E Instruction Guide
- F Warranty


Components

- G Release Button
- H Plug Selectors


Getting Started

Press and hold the release button (G) and slide a plug selector (H) forward into the locked position.
To choose a different plug, press and hold the release button, slide plug selector back, then slide a different
plug selector forward.






Plug your device's AC or USB cord into the corresponding adapter cap (B or C). To remove the wall adapter or USB adapter cap press and hold the release button and then remove the cap.




3. Plug the International Travel Plug Adapter (A) into a power outlet. The battery indicator/charging light comes on. If you are using an iPod shuffle, it may take up to one minute for the light to come on.




Fuse Information

The International Travel Plug Adapter (A) comes with a fuse installed and an extra fuse (D) located in the wall adapter cap (B). Use only T2.5A fuses with the International Travel Plug Adapter.

If you need to replace the fuse:





- 1. Remove the extra fuse from the wall adapter cap (B). With the tip of a pen, press on the plastic notch located next to the fuse, and then turn the wall adapter cap upside down. The fuse should fall out of the cap.
- 2. Remove the fuse from the International Travel Plug Adapter. Using a coin, turn the fuse cover and pop out the fuse.
- 3. Insert the extra fuse into the International Travel Plug Adapter.

WARNING: Not for use with hairdryers or similar high powered devices (irons, curlers etc.)

▲ WARNING: Using the Travel Plug Adapter with the AC Cap allows your electronic equipment's plug to fit into electrical outlets worldwide, but does not reduce or convert electrical AC Voltage.

Using the travel plug adpater in a power source with voltage higher or lower than your electronic equipment specifies creates a risk of damaging or destroying the equipment and a risk of other safety hazards.

Note, however, that using the Travel Plug Adapter with the USB adapter does convert the voltage in any outlet worldwide to the correct voltage for USB.

WARNING: Failure to read and follow the safety instructions in this Instruction Guide before using your Travel Plug Adapter with AC Cap or USB Adapter Cap could result in serious or fatal injury and property damage.

Registering Your Kensington Product

Register your Kensington product online at www.kensington.com.

Usage

The International Travel Plug Adapter with USB Charger can be used with Class II electronic devices up to 2.5A (110V n 275W / 220V n 550W). Most consumer electronic devices, such as mobile phones, PDAs, laptop computers, alarm clocks, battery chargers, and more, are Class II devices. Any use of this product other than as described in the instructions above will void the warranty.

The manufacturer declines any responsibility in case of damage.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com