


**COOKTOP PARTS**

For Model: KDSS907SSS01

(Stainless)

30" Slide-In  
Dual Fuel  
CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS

For Models: KDSS907SSS01


(Stainless)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Literature Parts
	W10118264	Installation Instructions
	W10118263	Use & Care Guide
	W10112147	Tech Sheet
	9757680	Anti-Tip Instructions
		Safe Cooking Tips
	3191638	English
	9759133	French
	9763467	Guide Easy Set
2	W10110471	Burner Box
3	9761784	Bracket, Mounting
4	W10106360	Cooktop
5	3196537	Screw
6	9757807	Thermostat
7	3400843	Screw
8	W10108030	Bracket, Spark Module
9	9763445	Bracket, Burner
10	8301084	Shield, Heat
11	8522426	Module, Spark
12	9761555CB	Grate, Burner (RH)
13	9761556CB	Grate, Burner (LH)
14	3368921	Screw
16	9759944	Thermostat
18	9761557CB	Grate, Insert
19		Cap, Burner
	9761563CB	12.5K (RR)
	8284669	6K (RF, LR)
21	3196160	Screw
23	9761755	Cover, Cooktop Rear
24	9763436	Cover, Top Rear
25		Head, Burner
	8286182	Large (RR)
	8286181	Small (LR,RF)
26	W10109920	Gasket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KDSS907SSS01  
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS


For Models: KDSS907SSS01  
(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side	20		Body, Side	42	4449868	Block, Terminal
	W10109560	Right		9760723PB	Black	43	3400080	Screw
	W10109510	Left	21	9757461	Bracket, Side Panel	44	9757404	Box, Terminal
2	3400832	Screw	22	9760888	Latch, Motorized	45	9757405	Cover, Terminal
3		Hinge Receiver	23	9759242	Thermostat			Box
	4455606	Right	24	9757811	Brace, Side Panel	46	9759721	Insulator,
	4455605	Left	25	4455641	Side, Chassis			Terminal Box
4	W10105790	Bumper, Door (2)	26	9759761	Back, Chassis	47	9761958	Block, Terminal
5	3196537	Screw	27		Liner, Oven	48	9756454	Bracket, Appliance
6	3196160	Screw			(Not Serviceable)			Manager
7	8303099	Top Chassis	28	9759890	Clip, Side Panel	49	W10083460	Slide, GOC
8	4449809	Screw	29	4455636	Sensor	50	9761801	Appliance Manager
9	4452158	Tube, Vent	30	9759884	Insulation	51	9759320	Blower
10	W10067870	Lens, Light (2)	31	3196176	Screw	52	9756821	Support, Wiring
11	W10009930	Oven Light, Assembly (2)	32	9757829	Bracket, Transformer	53	3196537	Screw
12	4452166	Bulb, Light (2)	33	9759713	Base, Chassis	54	9759945	Stand Off-Rear
13	4449154	Screw	34	4448933	Retainer, Gasket	55	3400805	Screw
14	9760756	Frame, Front	35	9758583	Cover, Back	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
15	W10074200	Gasket, Door	36	9756481SS	Vent, Bottom Upper	<b>INSULATION</b>		
16	4448444	Grommet, Mounting Rail	37	W10104870	Vent, Bottom Lower			
17	4452152	Bracket, Mounting	38	4449743	Screw			
18	9757685	Guide, Side Panel	39	9759722	Insulation, Side Trim			
19	4451478	Support, Insulation	40	4448717	Rack, Oven		9756817	Insulation, Wrap
			41	9760212	Control, Transformer		9756470	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KDSS907SSS01  
(Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: KDSS907SSS01  
(Stainless)


Illus. No.	Part No.	DESCRIPTION
1	9759413	Panel, Door
2	9757706	Glass, Inner
3	4451722	Insulation, Door
4	4457132	Retainer, Glass
5		Hinge, Oven Door
	9760579	Right
	9760580	Left
6	9759225	Glass, Inner
7	4457114	Shield, Heat Bottom
8	9759229	Bracket, Glass Side
9	4457103	Shield, Heat Top
10	9759225	Glass, Inner Door
11	9759230	Bracket, Central
12		Bracket, Handle
	9763497	Right
	9763496	Left
13	8522415	Seal, Window
14	W10131121	Assembly, Door Kit
15	8303774SS	Handle, Door
16	3196184	Screw
17	4448520	Bumper, Door (3)
18	8304603SS	Badge

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER PARTS

For Models: KDSS907SSS01

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Support, Drawer Rail
	9757687	Right
	9757686	Left
2	9763501BL	Support, Front & Rear
3		Brace, Drawer
	4453720	Right
	4453721	Left
5		Side, Base
	9759953	Right
	9759954	Left

Illus. No.	Part No.	DESCRIPTION
6	W10058460	Foot
8	3196037	Foot Assembly
10	9757805	Drawer
11		Guide, Roller Includes Roller
	W10019810	Right
	W10019800	Left
12	9763456	Panel, Drawer
13	9761747SS	Front, Drawer
14	9761573SS	Handle, Drawer
15	3196537	Screw


Illus. No.	Part No.	DESCRIPTION
16	8274149	Thermistor
17	9760775	Element, Warming
18	4449809	Screw
19	9758676	Support, Element
20	9763491	Bracket, Regulator
21	W10108850	Regulator
22	W10045140	Cover, Terminal
23	9761796	Enclosure, Warming Drawer
24	W10118828	Cover, Access
25	3400805	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: KDSS907SSS01

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	9759938	Bracket, Terminal Box
7	4449809	Screw
10	4449040	Screw
11	4455352	Bracket, Blower


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# INTERNAL OVEN PARTS

For Models: KDSS907SSS01

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4448717	Rack, Oven
3	9760768	Element, Bake
4	4455037	Tray, Bake Hidden
5	9756690	Cover, Fan

Illus. No.	Part No.	DESCRIPTION
6	4449154	Screw
8	4449809	Screw
9	9760769	Element, Convection
10	4452226	Blade, Fan
11	4452227	Nut
12	4451583	Motor, Convection


Illus. No.	Part No.	DESCRIPTION
13	9755543	Jack, Meat Probe
14	9755542	Probe, Meat
15	9755547	Lock Washer
16	9755546	Hex Nut
17	4450039	Cover, Bake Tray

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP BURNER PARTS

For Models: KDSS907SSS01

(Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base Includes Orifice
	W10128455	RR
	W10128446	RF, LR
2	9761069	Tubing, Burner(RF)
3	9761070	Tubing, Burner(RR)
4	9761068	Tubing, Burner(LR)
5	4456816	Valve, Burner Small (2)


Illus. No.	Part No.	DESCRIPTION
6	4456817	Valve, Burner Large
7	9756824	Spark Switch & Harness Assembly
8	9761752	Tube, Manifold
9		Manifold
	9761641	TCB
	9761642	Cooktop
11	3196537	Screw
12	8523704	Bolt, Valve (4)

Illus. No.	Part No.	DESCRIPTION
13	W10108840	Tubing DF to Regulator
14	W10110378	Igniter, Orifice Holder
15		Orifice
	9762938	RR
	9762937	LR, RF
16	8273062	Screw


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TRIPLE CROWN BURNER

For Models: KDSS907SSS01  
(Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9761639	Burner Assembly Triple Crown Burner
2	8285250	Plate, Closure
3	8285255	Internal Head, Triple Crown Burner
4	8285256	External Head, Triple Crown Burner
5	8285258	Cap, Burner External
6	9758829CB	Cap, Burner Internal
7	3400702	Screw
8	3400843	Screw
9	9760519	Valve, TCB
10		Tube, TCB Gas
	9761072	Outer
	9761071	Inner
11	9763494	Igniter
12		Orifice
	9762443	Internal
	9762442	External



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: KDSS907SSS01  
(Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10117043	Control Panel
2	9761566	Switch, Membrane
3	9761799	Control, Interface
4	W10105370	Shield, Console
5	3196537	Screw
6	9761745	Bracket, Touchsensor
7	W10114682	Knob (LF)
8	W10114692	Knob (LR, RF, RR)
9	9780271	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: KDSS907SSS01

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>			<b><u>SPLICING WIRES--25FT. LENGTH</u></b>			<b><u>WIRING HARNESS PARTS</u></b>		
	72017	White		242828	Wire (12 Ga. 150 c Black)		W10110729	Harness, Wire Main
	261869	Cord Brown		242820	Wire (14 Ga. 150 c Black)		W10118725	Harness, Switch Electric
	72032	Black		242821	Wire (14 Ga. 150 c Blue)		9756921	Harness, TCB
<b><u>PAINT, SPRAY</u></b>				242822	Wire (14 Ga. 150 c Brown)		9762921	Harness, Communication
	350930	White		242830	Wire (14 Ga. 200 c Brown)		9763481	Harness, Ground Strap
	261900	Citrine White		242823	Wire (14 Ga. 150 c Green)		9762781	Harness, Wire Connector Cable
	830864	Black		242824	Wire (14 Ga. 150 c Orange)		9759715	Conduit, Slide In
<b><u>ADHESIVE</u></b>				242829	Wire (12 Ga. 150 c Red)		313660	Clip, Ground Wire
	591014	Adhesive Loctite (1/3 oz.)		242825	Wire (14 Ga. 150 c Red)		4448664	Clamp, Conduit
	482338	Sealer, Silastic (3 oz.)		242831	Wire (14 Ga. 200 c Red)		4449809	Screw
				242826	Wire (14 Ga. 150 c White)		112432	Nut
				242827	Wire (14 Ga. 150 c Yellow)		4452222	Spacer, Harness
				242832	Wire (14 Ga. 200 c Yellow)		3400015	Screw, Ground
							<b><u>Miscellaneous</u></b>	
							4455352	Bracket, Blower (60mm)
							9757426	Orifice Kit
							9782676	Anti-Tip Assembly
							9757427	Kit, Orifice

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>