


KitchenAid® COOKTOP PARTS

For Models: KECC507GBL2, KECC507GWH2, KECC507GAL2, KECC507GBT2, KECC507GWW2
(Black) (White) (Almond) (Biscuit) (Designer White)

30" ELECTRIC
BUILT-IN
COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Models: KECC507GBL2, KECC507GWH2, KECC507GAL2, KECC507GBT2, KECC507GWW2
 (Black) (White) (Almond) (Biscuit) (Designer White)

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-----------------------------------|
| 1 | 4455468 | Shield, Heat |
| 2 | | Cooktop, Glass |
| | 4455297 | Black |
| | 4455293 | White |
| | 4455292 | Honeycomb |
| | 8284699 | Designer White |
| 3 | 246119 | Screw |
| 4 | 4455421 | Bracket, Switch |
| 5 | 3191839 | Seal, Heat Shield |
| 6 | 3191791 | Spring Locator (8) |
| 7 | | Switch, Infinite |
| | 3191049 | Use W/1500W Left Rear Burner |
| | 3188516 | Use W/1800W Right Rear Burner |
| | 3191049 | Use W/1200W Right Front Burner |
| | 3188516 | Use W/2400 W Left Front Burner |
| 8 | 3183956 | Seal, Switch Shaft |
| 9 | 3191945 | Light, Indicator |
| 10 | | Knob, Control (4) |
| | 9750372FF | Black |
| | 9750372FW | White |
| | 9750372FT | Almond |
| | 9750372FC | Biscuit |
| 11 | 4456401 | Box, Burner |
| 13 | 3192477 | Bumper, Silicone |
| 14 | 3196537 | Screw |
| 15 | 3182435 | Seal, Switch (4) |
| 17 | 311865 | Screw |
| 20 | 3191515 | Rail, Element (2) |
| 21 | 3192268 | Rail, Element (1) |
| 22 | 3191343 | Lamp, Hot Surface Indicator |
| 24 | | Element, Surface |
| | 4452742 | 1200W – RF |
| | 4452743 | 1500W – LR |
| | 4452741 | 1000/1800W – RR |
| | 8272563 | 1000/2400W – LF |
| | 3192737 | Seal, Heat |
| | 3192439 | Seal, Limiter |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: KECC507GBL2, KECC507GWH2, KECC507GAL2, KECC507GBT2, KECC507GWW2

(Black)

(White)

(Almond)

(Biscuit)

(Designer White)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

**FOLLOWING PARTS
NOT ILLUSTRATED**

LITERATURE PARTS

LIT3192799 Installation Instructions
 LIT3191795 Wiring Diagram
 LIT8284718 Use & Care Guide
 LIT3191638 Safe Cooking Tips

Miscellaneous

3172515 Mtg. Hardware Kit
 4455364 Bracket, Support (4)
 3192408 Bracket, Support (2)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

SPLICING WIRES--25FT.

LENGTH

242828 Wire, Black
 12 Ga. 150° C
 242820 Wire, Black
 14 Ga. 150° C
 242822 Wire, Blue
 14 Ga. 150° C
 242830 Wire, Brown
 14 Ga. 200° C
 242823 Wire, Green
 14 Ga. 150° C
 242824 Wire, Orange
 14 Ga. 150° C
 242829 Wire, Red
 12 Ga. 150° C
 242825 Wire, Red
 14 Ga. 150° C
 242831 Wire, Red
 14 Ga. 200° C
 242826 Wire, White
 14 Ga. 150° C
 242827 Wire, Yellow
 14 Ga. 150° C
 242832 Wire, Yellow
 14 Ga. 200° C

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

ACCESSORY PARTS

3191048 Cleaner, Glass

WIRING HARNESS PARTS

4455273 Wiring Harness Surface Unit
 3400015 Screw, Ground
 3192220 Conduit Assy.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>