


KitchenAid® COOKTOP PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
 (White) (Biscuit) (Stainless Steel) (Black)

30" Freestanding
 Gas Range
 DESIGNER STYLE
 Convection Oven



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS


For Models:KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	8	9753691	Bracket, Support	18		Cap, Vent
	LIT9753562	Installation Instructions	9		Cover, Light		9751271GW	White
	LIT9753620	Use & Care Guide		9751327	White		9751271GB	Black
	LIT9752686	Smart & Easy Guide		9751632	Black	19	9751366	Cap, Vent
	LIT9753621	Tech Sheet	10	9753320	Biscuit	20	9751984	Fuse, Bi-Metal
	LIT9753622	Wiring Diagram			Backsplash	22	9752006	Thermostat, Fixed
	LIT9752775	Template, Anti-Tip		9781896GB	Black	23		Bumper, Rubber
	LIT3191638	Safer Cooking Tips		9781896GW	White		9750969	White
	LIT9753848	LP Installation Instructions		9781896GC	Biscuit		9780771	Black
2	9754102	Gasket, Cooktop	11		Bezel, Burner	26	9751664	Cover, Backsplash
3		Trim, Cooktop (Right Hand)		9753601GS	6K RF-LR	27		Endcap, Backsplash (Right Hand)
	9751275PW	White		9753602GS	12K RR		9781885FB	Black
	9751275PB	Black		9753600GS	14K LF		9781885FW	White
	9751275PC	Biscuit (Left Hand)			Black		9781885FC	Biscuit (Left Hand)
	9751276PW	White		9753601GB	6K RF-LR		9781884FB	Black
	9751276PB	Black		9753602GB	12K RR		9781884FW	White
	9751276PC	Biscuit	13	9753600GB	14K LF		9781884FC	Biscuit
4	9781982	Gasket, Cooktop			Grate, 2 Burner	28		Glass, Backsplash
5	9754197	Support, Burner		9753616GS	Mouse Gray		9753910CW	White
6	9751629	Bracket, Pivot	15	9752638	Pad, Grate (4)		9753910CB	Black
	9752003	Washer, Pivot	16		Cap, Burner		9753910CC	Biscuit
7		Cooktop, Glass		3191899	Mouse Gray		9753292	Clear Glass (Stainless Model)
	9753606CO	Opaque White		3191905	6K RF-LR	29	9781490	Seal
	9753606CB	Black		9753939GS	12K RR	30	9754071	Panel, Backguard (Stainless)
	9753606CT	Biscuit			14K LF			Screw, 10-16 x 3/8
				3191898	Black	32	9780265	Screw, 10-16 x 1/2
				3191904	6K RF-LR	33	3149333	Screw, 10-16 x 1
				9753939GB	12K RR	34	9751871	Screw, 10-16 x 1
			17	341196	14K LF			
					Thermo-Disc			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP BURNER PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Burner Base W/Orifices	7		Valve, Burner	16		Orifice, Burner
	9754183	6K RF-LR		9753045	6K RF-LR Red Stem		9753928	6K RF-LR
	9754189	12K RR		9753044	12K RR Black Stem		9753929	12K RR
	9754192	14K LF		9753614	14K LF Plain Stem		9753930	14K LF
2	9753610	Tubing, Burner(RF)	8	3185829	Bolt, Gas Valve(4)	18	9751854	Tubing, Flex
3	9753611	Tubing, Burner(RR)	9	9752994	Spark Switch & Harness Assembly	19		Head, Burner
4	9753608	Tubing, Burner(LF)	11		Manifold		8273216	6K RF-LR
5	9753609	Tubing, Burner(LR)		9754116L	Left Hand		8273214	12K RR
6	9754148	Tubing, Manifold		9754116R	Right Hand		4455849	14K LF
			13	9754215	Electrode		9754136	Pad, Burner Ring
						20	8281147	Screw, 8-18 x 5/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
 (White) (Biscuit) (Stainless Steel) (Black)




Illus. No.	Part No.	DESCRIPTION
1		Console, Glass
	9781973CW	White
	9781973CB	Black
	9781973CC	Biscuit
2	9781980	Timer, Electronic
3	9780271	Screw, 8-18 x 1/4
4		End Cap
		Right Hand
	9751280FW	White
	9751280FB	Black
	9751280FC	Biscuit
		Left Hand
	9751279FW	White
	9751279FB	Black
	9751279FC	Biscuit
7	9780265	Screw, 10-16 x 3/8
8		Knobs, Control
	9751199FW	White
	9751199FF	Black
	9751199FC	Biscuit
23	3191387	Seal, Switch
24	9781488	Spacer, Bottom Trim

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS


For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
 (White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2		Trim, Door-Left	6		Vent, Door	21	9750169	Bracket, Drawer
	9782003PW	White		9753498GW	White	22	423713	Support, Roller
	9782003PB	Black		9753498GB	Black	23	9750676	Retainer, Door
	9782003PC	Biscuit		9753498GC	Biscuit	24		Front, Drawer
3		Trim, Door-Right		9781490	Seal, Door		9782108PW	White
	9782004PW	White		9781659	Gasket, Vent		9782108PB	Black
	9782004PB	Black	8		Handle, Door		9782108PC	Biscuit
	9782004PC	Biscuit		9780523PW	White		9782109PB	For Stn.Steel MDL
4		Trim, Door Bottom		9780523PB	Black	25	9750693	Heat, Channel
	9781209PW	White		9780523PC	Biscuit	27	90296	Clip
	9781209PB	Black	9	9781449	Gasket, Door Glass	28	9781502	Retainer, Glass
	9781209PC	Biscuit	10	9782033	Hinge, Door R or L	29	9780265	Screw
5		Glass, Door	12	9781602	Frame, Window	30	3400075	Screw
	9781627PW	White	13	9781586	Shield Door	31	9781072	Screw
	9781627PB	Black	14	9780771	Bumper, Rubber	33		Stainless Model
	9781627PC	Biscuit	15	9781593	Glass, Door (2)	34	9750614PB	Trim, Drawer-Top
	9754041	Stainless	16	9755177	Seal, Glass	35	9753329	Spacer
			18	9754006	Insulation	36	9754062	Panel, Drawer
			19	9781600GM	Liner, Door	37	9750613PB	Trim, Drawer-Btm
			20	9780583	Drawer & Roller			
				9750257	For Stn. Steel MDL			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
 (White) (Biscuit) (Stainless Steel) (Black)


Illus. No.	Part No.	DESCRIPTION
1	8053421 98997	Module, Spark Clip
2	9750514GM	Chassis, Front
5	9753335GM	Oven Liner
6	9755179	Gasket Oven
7		Oven, Side L or R
	9781907PW	White
	9781907PB	Black
	9781907PC	Biscuit
8	9780664	Shield, Insulation
9	9751789	Fan Duct, Side
10	9782329	Duct
11	9752637	Burner Box
12	9752735	Retainer, Insulation
13	9751653	Duct, Top
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left
	9750224	Drawer Rail, Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9782005	Hinge, Door L or R
21	9782051	Shield, Drawer
22	9782050	Plate, Reflectance
23	9780265	Screw, 10-16 x 3/8
24	9782326	Shield, Heat
25	9751592	Vent Tube
29	9781581	Door Switch
30	9751808	Screw, 8-18 x 1
31	9780270	Screw, 8-18 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BROILER & OVEN BURNER PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)


Illus. No.	Part No.	DESCRIPTION
1	9752737	Shield, Oven (2)
2	9752738	Flame Shield, Bake
3	9752922	Burner, Broiler
4	9751367	Burner, Bake
6	9753108	Ignitor,
7	9752858	Bracket, Broil Shooter
8	9752736GM	Pan, Oven Bottom
9	9782061	Tubing, Broil
10	9752698	Valve & Regulator Assembly
11	776593	Screw, 1/4-20x1/2
12	9781015	Tubing, Valve To Regulator
13	9752734	Pan Support, Bake
14	9751600	Bracket, Bake
15	9751203	Nut #18 5/8
16	9752920	Coverbox (Broiler Tubing)
17	9752716	Orifice #54
18	9751643	Screw, 10-24 x 3/8
19	9780265	Screw, 10-16 x 3/8



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9781543	Assembly, Fan
2	9780272	Screw, 10-16 x 1/2
9	9751904GM	Baffle, Convection
	9780270	Screw, (2) 8 x 3/8
10	4167277	Lock-Nut, Cvr.Jack
11	4167266	Jack Cover
12	305289	Gasket


Illus. No.	Part No.	DESCRIPTION
13	4173575	Receptacle, Probe
14	3179672	Spacer, Tubing
15	8935	Bulb, Oven
16	9781050	Light, Socket
17	3150144	Probe
18	420104GM	Grill, Broiler
19	420101GM	Pan, Broiler

Illus. No.	Part No.	DESCRIPTION
20	9750827	Rack, Roasting
21	9750823	Rack, Standard (3)
22	9782081	Sensor
23	9781049	Lens, Light
24	3184533	Gasket, Lens
25	9780265	Screw, 8-32 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR CHASSIS PARTS

For Models: KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9751051	Back, Chassis
2	340184	Screw, 10-16 x 1.5
3	9751353	Panel, Rear Cover
4	423247	Screw, 10-16 x 3/8
5	9751418	Bracket, Lock
6	9751500	Bracket, Regulator Valve

Illus. No.	Part No.	DESCRIPTION
7	9751439	Oven Lock Assy.
8	9751590	Solenoid
9	422222	Screw, 10-32 x 5/16
10	424238	Washer, #10 Lock
12	9751763	Switch, Interlock

Illus. No.	Part No.	DESCRIPTION
13	9750887	Screw, 4-40 x 1
14	9750888	Nut (2)
15	9750523	Rod, Lock
17	258076	Block, Terminal
18	98884	Screw, 10-16 x 1
19	9780265	Screw, 10-16 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models:KGRT607HWH5, KGRT607HBT5, KGRT607HBS5, KGRT607HBL5
(White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION
<u>SPLICING WIRES--25FT. LENGTH</u>		
242828		Wire, Black 12 Ga. 150°c
242820		Wire, Black 14 Ga. 150°c
242821		Wire, Blue 14 Ga. 150°c
242822		Wire, Brown 14 Ga. 150°c
242830		Wire, Brown 14 Ga. 200°c
242823		Wire, Green 14 Ga. 150°c
242824		Wire, Orange 14 Ga. 150°c
242829		Wire, Red 12 Ga. 150°c
242825		Wire, Red 14 Ga. 150°c
242831		Wire, Red 14 Ga. 200°c
242826		Wire, White 14 Ga. 150°c
242827		Wire, Yellow 14 Ga. 150°c
242832		Wire, Yellow 14 Ga. 200°c
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	72107	Almond
	511873	White Porcelain (2 Oz.)
	4392899	Biscuit

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	350956	Almond
	285006	Superior Black
	206922	Primer (White)
	4392901	Biscuit
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)
	978883	Almond (Uncut)
	4392900	Biscuit (Uncut)
<u>REFINISHING MATERIAL</u>		
	799832	Kit, Porcelain Repair (White)
	242756	Touch-Up Self-Clean (1/2 Pt.)
<u>INSULATION</u>		
	9754004	Insulation, Wrap
	9754011	Insulation, Rear
	9754005	Insulation, Bottom
	9754301	Insulation, Flue Cut Out
<u>CLEANER, COOKTOP</u>		
	9753543	Glass Cleaner
	3183488	Scrapet

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORIES</u>		
	241430	Foil, Aluminum Oven (18" X 25')
<u>CONVERSION KIT</u>		
		Gas Conversion Kit
	9753604	LP
	9752717	Natural
<u>LUBRICANT</u>		
	261582	Grease
<u>ANTI-TIP KIT</u>		
	9751745	Anti-Tip Kit
<u>WIRING HARNESS PARTS</u>		
	9782134	Harness, Wire (Main Harness)
	9751708	Harness, Wire (Neutral Gas)
	9753808	Harness, Wire (Spark Control)
	9750376	Harness, Wire (Oven Door)
	9753374	Harness, Wire (Dual Oven Light)
	9752769	Harness, Wire (Spark Module)
	20082084	Tie, Wire
	9781555	Clip, Wire
	9751868	Grommet Harness (2)
	3196520	Clip, Wire
	9781055	Power Cord

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>