


KitchenAid®

9-CUP FOOD PROCESSOR

MODELS:

KFP0922WH0 (White)
KFP0922OB0 (Onyx Black)
KFP0922CU0 (Contour Silver)
KFP0922BD0 (Brushed Chrome)
KFP0924CU0 (Contour Silver)

MOTOR AND HOUSING UNIT















MOTOR AND HOUSING UNIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10414535	Use and Care Guide
2	W10451329	Cord, Power (2-Prong)
3	W10451320	Foot

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10466880	Shaft, Motor
5	W10466886	Panel, Control
6	W10466879	PCBA Assembly
7	W10466885	Nameplate
8	W10451322	Block, Terminal

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10467162	Motor
10		Base, Housing
	W10592577	Onyx Black

ATTACHMENT PARTS



ATTACHMENT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10466829	Blade, Multipurpose
2	W10466831	Blade, Mini
3	W10466836	Blade, Dough
4	W10466837	Blade, Adjustable Slicing
5	W10466841	Disc, Shredding
6	W10466843	Adapter, Shredding

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10466847	Pusher, Round
8	W10466865	Pusher, Regular
9	W10466876	Pusher, Wide Mouth
10	W10466844	Lid, Clear
11	W10466846	Bowl, Mini
12	W10466845	Bowl, 9-Cup (Clear)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10480167	Gasket, Lid
		OPTIONAL PARTS NOT ILLUSTRATED
	W10633132	Disc, Cutting (French Fry)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>