


For Models: KEBK276SBL02, KEBK276SWH02, KEBK276SSS02
(Black) (White) (Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:KEBK276SBL02, KEBK276SWH02, KEBK276SSS02
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12	W10169757	Bulb, Light	28	8304452	Thermal Fuse 105C
	8304336	Installation Instructions	13	3400832	Screw (2)	29	W10131825	Sensor
	W10162179	Use & Care Guide	14	8304629	Frame, Front	30	8303724	Vent, Center
		Tech Sheet	15	8304494	Gasket, Door	31	8303772	Base, Chassis
	W10220954	English	16	3196176	Screw	32	8304478	Retainer, Gasket
	W10220955	French	17	4449040	Screw	33	8303517	Cover, Back
	8304335	Easy Set Guide	18	4449154	Screw	34		Trim, Bottom Vent
		Safer Cooking Tips	19	4451477	Support, Insulation		8303706BL	Black
	9762761	English	20	4450038	Screw (2)		8303706WH	White
	9759133	French	21		Mounting Rail,Side Right		W10165444	Stainless
				8303677BL	Black	35	4448444	Grommet, Mounting Rail
2	W10153090	Bracket, Base		8303677WH	White	37	W10169348	Bracket, Thermostat
3		Hinge Receiver			Left			
	4455606	Right		8303678BL	Black			
	4455605	Left		8303678WH	White			
4	W10105790	Bumper, Door (2)	22	W10195935	Latch, Mortorized			
5	8303829	Exhaust,Vent Slope	23	4449743	Screw			
6	W10181198	Divider, Vent	24	4449748	Screw			
7	W10204469	Top Chassis	25	4455641	Side, Chassis			
8	4449809	Screw	26	8304304	Back, Chassis			
9	4452158	Tube, Vent	27		Liner, Oven (Not serviceable)			
10	W10169756	Lens, Light						
11	W10009940	Oven Light Assembly						

FOLLOWING PARTS NOT ILLUSTRATED


INSULATION

8303966 Insulation, Wrap
8303968 Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models:KEBK276SBL02, (Black)
 KEBK276SWH02, (White)
 KEBK276SSS02 (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8303717BL 8303717WH W10165446	Panel, Control Black White Stainless
2	8303687	Support, Appliance Manager
4	8304333	Keyboard, Glass Touch
5	W10172472	User Interface
6	8303720	Backer, Control
7	8303887	Bracket, Enclosure (2)
8	4449154	Screw
9	3400832	Screw
10	W10119142	Appliance Manager
11	8304441	Resistor, Drop
12	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEBK276SBL02, KEBK276SWH02, KEBK276SSS02
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8304522	Bumper, Door	11	8304361BL	Bracket, Handle	13		Door Handle
2	W10174288	Hinge, Door (2)	12		Door Glass, Assembly		8303775BL	Black
3	3196183	Screw			Lower Includes #17		8303775WH	White
4	8304580BL	Vent, Door Top		8304001	Black		8303775SS	Stainless
5		Bracket, Door		8304003	White	15	8303745BL	Frame, Door Side(2)
	8304377	Right		8303999	Stainless	16	8303754	Door, Top Bracket
	8304378	Left			Door Glass, Assembly	17		Badge
6	8303738BL	Door Liner			Upper No Badge		8304603BL	Black
7	8303732	Glass, Inner		8304002	Black		8304603WH	White
8	4449743	Screw		8304004	White		8304603SS	Stainless
9		Cover, Hinge		8304000	Stainless			
	W10137044	Right						
	W10137043	Left						
10	8304523	Seal						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEBK276SBL02, KEBK276SWH02, KEBK276SSS02
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8304602	Element, Broil Shield
2	9760774	Element, Broil
3	4449154	Screw
4	4448715	Rack, Oven
6	9760768	Element, Bake
7	4455036	Tray, Bake
8	4450039	Cover, Bake Tray
9	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEBK276SBL02, KEBK276SWH02, KEBK276SSS02
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752759	Relay (2)
2	8304643	Duct, Air Outlet
3	4449809	Screw
4	8303972	Blower, 60mm
6	8285593	Connector, Cover
7	W10111628	Transformer, Control
8	4450118	Nut
9	4449868	Block, Terminal
10	3400080	Screw
11	8303722	Vent, Control Panel
12	8303518	Side, Control Top Right
	8304255	Left
13	8303520	Back, Control
14	8304220	Cover, Top
15	7103P027-60	Nut (3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models:KEBK276SBL02, KEBK276SWH02, KEBK276SSS02
(Black) (White) (Stainless)

Illus.	Part	
No.	No.	DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10143473 Harness,
Door Latch
W10171562 Harness, Main
8304051 Harness, Wire
Communication
8304439 Conduit, Double
4450800 Screw,Ground
4454842 Tie, Cable

Miscellaneous

4448950 Screw, Install (4)
98997 Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>