

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KEBS107SBL04, KEBS107SWH04, KEBS107SSS04
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8304336	Literature Parts Installation Instructions	9	4452158	Tube, Vent	24	W10169348	Bracket, Thermostat
	8304571	Installation Instructions Undercounter	10	W10169756	Lens, Light	25	4455641	Side, Chassis
	W10162180	Use & Care Guide Tech Sheet	11	W10009940	Assembly, Oven Light	26	8304303	Back, Chassis
	W10220952	English	12	W10169757	Bulb, Light	27		Liner, Oven (Not serviceable)
	W10220953	French	13	3400832	Screw (2)	28	8304452	Thermal Fuse
	8304335	Easy Set Guide Safer Cooking Tips	14	W10115861	Frame, Front	29	W10131825	Sensor
	9762761	English	15	8304493	Gasket, Door	31	8303516	Base, Chassis
	W10065852	French	16	3196176	Screw	32	8304478	Retainer, Gasket
2	W10153090	Bracket, Base	17	4449040	Screw	33	8303517	Cover, Back
3	4455606	Hinge Receiver Right	18	4449154	Screw	34		Trim, Bottom Vent
	4455605	Left	19	4451478	Support, Insulation		8303705WH	White
4	W10105790	Bumper, Door (2)	20	4448444	Grommet, Mounting Rail		8303705BL	Black
5	8303829	Exhaust, Vent Slope	21		Mounting Rail, Side Right		W10216230	Stainless
6	W10181196	Divider, Center Vent		8303675BL	Black	FOLLOWING PARTS NOT ILLUSTRATED		
7	W10204470	Top Chassis		8303675WH	White	INSULATION		
8	4449809	Screw		8303676BL	Black		8303965	Insulation, Wrap
				8303676WH	White		8303967	Insulation, Back
			22	W10195935	Latch, Mortorized			
			23	4449743	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KEBS107SBL04, KEBS107SWH04, KEBS107SSS04
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8303716BL 8303716WH W10216219	Panel, Control Black White Stainless
2	8303687	Support, Appliance Manager
4	8303879	Control Panel, Glass Touch
5	W10118733	User Interface
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10119143	Appliance Manager
11	8304441	Resistor, Drop

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEBS107SBL04, KEBS107SWH04, KEBS107SSS04
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8303737BL	Door Liner	10	8304523	Seal	15	8303745BL	Frame, Door Side
2	W10174285	Hinge, Door (2)	11	8304360BL	Bracket, Handle	16	8303746	Bracket, Top Door
3	3196183	Screw	12		Door Glass, Assy Includes #17	17		Badge
4	8304581BL	Vent, Door Top		8303993	Black		8304603BL	Black
5		Bracket, Door		8303995	White		8304603WH	White
	8304377	Right		W10237350	Stainless		8304603SS	Stainless
	8304378	Left	13		Door Handle	18	8304522	Bumper, Glass
6		Cover, Hinge		8303774BL	Black			
	W10137044	Right		8303774WH	White			
	W10137043	Left		8303774SS	Stainless			
7	8303731	Glass, Inner						
8	4449743	Screw						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEBS107SBL04, KEBS107SWH04, KEBS107SSS04
(Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	8304602	Shield, Element Broil
5	8303841	Rack, Oven
6	W10208155	Oven Rack
7	9760768	Element, Bake
8	4455037	Tray, Bake
9	4449154	Screw
10	4450039	Cover, Bake Tray
11	4449809	Screw
12	8303962BU	Cover, Fan
13	9760769	Element Convection
14	9755543	Jack, Meat Probe
15	9755542	Probe, Meat
16	W10116351	Blade, Fan
17	W10116349	Nut
18	W10116228	Fan, Convection
19	9755547	Washer, Lock
20	9755546	Nut, Hidden

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEBS107SBL04, KEBS107SWH04, KEBS107SSS04
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

2	8304643	Duct, Air Outlet
3	4449809	Screw
4	8303972	Blower, 60mm
6	8285593	Connector, Cover
7	W10111628	Control, Transformer
9	4449868	Block, Terminal
10	3400080	Screw
11	8303684	Vent, Control Panel
12	8303518	Side, Control Top Right
	8304255	Left
13	8303520	Back, Control
14	8304219	Cover, Top
15	7103P027-60	Nut (3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEBS107SBL04, KEBS107SWH04, KEBS107SSS04
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10143473 Harness, Door
Latch
W10155291 Connector, Flex
W10171559 Harness, GOC
8304051 Harness, Main
8304438 Conduit, Single
4450800 Screw, Ground
4450118 U-Nut
4452260 Spacer, Foam
98997 Clip

Miscellaneous

4448950 Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>