


KitchenAid®

OVEN PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
(BLACK) (WHITE) (STAINLESS)

27" BUILT-IN ELECTRIC
COMBO OVEN
THERMAL CONVECTION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
(BLACK) (WHITE) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	W10204469	Top Chassis	29	W10131825	Sensor
	8304337	Installation	8	4449809	Screw	30	8303724	Vent, Center
		Instructions	9	4452158	Tube, Vent	31	8303772	Base, Chassis
		Use & Care Guide	10	W10169756	Lens, Light	32	8304478	Retainer, Gasket
	W10162223	Combo	11	W10009940	Assembly, Oven Light	33	8303517	Cover, Back
	W10162181	Microwave Tech Sheet	12	W10169757	Bulb, Light	34		Trim, Bottom
	W10185205	English	13	3400832	Screw (2)		8303706BL	Black
	W10185206	French	14	8304629	Frame, Front		8303706WH	White
		Easy Set Guide	15	8304494	Gasket, Door		W10165444	Stainless
	8304338	Oven	16	3196176	Screw	35	4448444	Grommet, Mounting Rail
	8304375	Microwave Safer Cooking Tips	17	4449040	Screw	36	W10169348	Bracket, Thermostat
	9762761	English	18	3400893	Screw	37	8304570	Support, Microwave Module
	W10065852	French	19	4451477	Support, Insulation			
			20	4450038	Screw (2)			
			21		Mounting Rail, Side Right			
2	W10153090	Bracket, Base		8303679BL	Black	FOLLOWING PARTS NOT ILLUSTRATED		
3		Hinge Receiver		8303679WH	White	INSULATION		
	4455606	Right			Left		8303966	Insulation, Wrap
	4455605	Left		8303680BL	Black		8303968	Insulation, Back
4	W10105790	Bumper, Door (2)		8303680WH	White			
5	8303829	Exhaust, Vent Slope	22	8303692	Latch, Motorized			
6	W10181198	Divider, Center Vent	23	4449743	Screw			
			24	4449748	Screw			
			25	4455641	Side, Chassis			
			26	8304304	Back, Chassis			
			27		Liner, Oven (Not serviceable)			
			28	8304452	Thermal Fuse			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
(BLACK) (WHITE) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
1	8303717BL 8303717WH W10165446	Panel, Control Black White Stainless
2	8304441	Resistor, Drop
3	8303797	Bracket, Glass Touch
4	8303881	Keyboard, Glass Touch
5	W10118734	Oven, User Interface
6	8303720	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10119143	Appliance Manager
11	W10118735	Microwave, User Interface
12	9760749	Bumper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
(BLACK) (WHITE) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8303738BL	Door Liner
2	W10174288	Hinge, Door (2)
3	3196183	Screw
4	8304580BL	Vent, Door Top
5	8304377	Bracket, Door Right
	8304378	Left
6	W10137044	Cover, Hinge Right
	W10137043	Left

Illus. No.	Part No.	DESCRIPTION
7	8303732	Glass, Inner
8	4449154	Screw
10	8304523	Seal
11	8304361BL	Bracket, Handle
12		Door Glass, Assembly Includes #17
	8304001	Black
	8304003	White
	8303999	Stainless

Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	8303775BL	Black
	8303775WH	White
	8303775SS	Stainless
15	8303745BL	Frame, Door Side
16	8303754	Door, Top Bracket
17		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless
18	8304522	Bumper, Glass

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERNAL OVEN PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02

(BLACK)

(WHITE)

(STAINLESS)




Illus. No.	Part No.	DESCRIPTION
1	8304602	Element, Broil Shield
2	9760774	Element, Broil
3	8303842	Rack, Oven
4	9760768	Element, Bake
5	4455036	Tray, Bake
6	4449154	Screw
7	4450039	Cover, Bake Tray
8	4449809	Screw
9	8304422BU	Cover, Fan
10	9760769	Element, Convection
11	W10116351	Blade, Fan
12	W10116349	Nut
13	W10196895	Motor, Convection Fan
14	9755543	Jack, Meat Probe
15	9755542	Probe, Meat
16	9755547	Washer, Lock
17	9755546	Nut, Hidden
18	8303840	Oven Rack (Sliding)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
 (BLACK) (WHITE) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	4449154	Screw
2	4454949	Holder, Fuse
3	4449809	Screw
4	8303972	Blower
6	8304643	Duct, Air Outlet
7	9762053	Transformer, Control
8	8285593	Control Cover
9	4449868	Block, Terminal
10	W10017410	Fuse
11	8304509	Back Chassis Panel
12		Side, Combo
	8304546	Right
	8303539	Left
13	8303538	Channel, Rear Combo
14	8303802	Cover, Top
15	7103P027-60	Nut, Terminal Block
16	3400080	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET AND STIRRER PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02

(BLACK)

(WHITE)

(STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
(BLACK) (WHITE) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10120227	Control, Electric	23	W10130895	Plate, Air	49	W10130904	Cover, Rear
2	8205669	Support	24	4375319	Spring, Lamp	50	8205680	Cover, Side Right
3	W10130892	Plate, Air	25	8205685	Spring	51	W10120221	Convection, Motor
4	W10130901	Insulation, Side Left	26	8205658	Housing, Lamp			Assmely
5	W10120471	Cover, Side Left	27	4375348	Lamp	52	8205721	Blower Assembly
6	W10120223	Thermostat	28	W10120222	Thermostat	53	W10130907	Cover, Inverter
7	W10120224	Element, Convection	29	W10131248	Switch	54	W10120229	Inverter
8	4375418	Fan	30	8205683	Holder, Switch	55	W10130906	Holder, Inverter
9	W10120233	Nut, Speed	31	4375320	Reflector	56	W10130890	Screw
10	W10130891	Holder	32	4375318	Lens, Lamp	57	W10130908	Baffle, Air
11	W10120220	Noise Filter	33	W10120231	Clip, Spring	58	W10130899	Plate, Air
12	W10120228	Control, Electric Converter	34	W10120476	Top Vent	59	W10120235	Rod, Release
13	W10130909	Bracket, Support	36	W10120472	Trim, Side Right	60	W10120225	Sensor
14	W10131249	Screw		W10120474	Left	61	8205685	Spring
15	8205692	Transformer	37	W10120469	Bushing	64	8205683	Interlock
16	4375427	Actuator	38	W10130905	Bracket, Support	65	W10130900	Insulation
17	4375321	Fuse	39	8205708	Bracket, Support	66	8205704	Spring
18	4375231	Block, Fuse	40	8205682	Shaft, Turntable	67	W10130902	Insulation
19	W10130897	Bracket, Support			Turntable	68	8205689	Spring
20	8205653	Filter, Noise	41	8205681	Cover, Motor	69	8205688	Arm
21	8205654	Thermostat			Turntable	70	8205686	Support
22	W10120113	Magnetron	42	W10120234	Cover	71	W10120236	Arm
			43	4375252	Gasket, Shaft	72	W10120470	Pin, Damper
			44	8205655	Motor, Turntable	73	8205690	Sensor
			45	4375202	Screw	74	W10130898	Duct, Magnetron
			46	8205707	Support			
			47	W10120478	Hinge, Door			
			48	W10130903	Cover, Plate			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERNAL MICROWAVE PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02

(BLACK)

(WHITE)

(STAINLESS)




Illus. No.	Part No.	DESCRIPTION
1	W10120480	Crisp Plate
2	W10120484	Steamer
4	W10120486	Plate, Baking
5	W10120483	Rack
6	8205676	Turntable
7	8205678	Ring
8	8205677	Drive, Turn Table
9	W10120481	Handle, Pan
10	W10120226	Grill Heater
11	W10120230	Cover, Plates (2)
12	W10120232	Bracket, Mounting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02
(BLACK) (WHITE) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	8304588BL	Button, Plug (2)
2	4449809	Screw
3	W10120488	Door, Microwave
4	4449154	Screw (4)
5	8303033	Bracket, Handle
6		Glass Assembly
	8304030	Black
	8304031	White
	8304029	Stainless
7		Handle, Door
	8303775BL	Black
	8303775WH	White
	8303775SS	Stainless
8	W10143304	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: KEMS378SBL02, KEMS378SWH02, KEMS378SSS02

(BLACK)

(WHITE)

(STAINLESS)

Illus.	Part	
No.	No.	DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

FOLLOWING PARTS NOT ILLUSTRATED

WIRING HARNESS PARTS

W10143473 Harness,
Door Latch
8304052 Harness,
User Interface
4452400 Lead, Ground
4449809 Screw
W10171567 Harness, Main
W10155291 Ground, Microwave
4450800 Screw, Ground
4449809 Screw
8304440 Conduit, Combo

Miscellaneous

4448950 Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>