


# Installation Instructions

## Flashguard LED Flasher Module To Flashguard Xtra

1. Straighten the two LEDs by gently bending them in to the upright position.
2. Peel the backing off the adhesive mounting brackets provided and attach them to the inside of the cover as shown below.




3. Connect the unit to a suitable 12V supply, observing polarity. The two LEDs will now flash alternately.
4. Slot the PCB into the mounting brackets with the LEDs pointing towards the lens. Bend the LEDs into position if required.
5. Fix the unit to the wall in the same way as an ordinary simulated unit.

# Installation Instructions

## Flashguard LED Flasher Module To Flashguard XL Plus

1. Straighten the two LEDs by gently bending them in to the the upright position.
2. Fix the board to the cut-out inside the cover using the self-ashesive pads provided. Screws can be used if desired.
3. Connect the unit to a suitable 12V supply, observing polarity. The two LEDs will now flash alternately.
4. Fix the unit to the wall in the same way as an ordinary simulated unit.



Part No. 102325

**Flash  
guard**

*The Installers Choice*

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>