


RINGER AMPLIFIER

INSTALLATION

Connect the telephone line to telephone line jack. Connect your telephone set to telephone jack. You can adjust the ringer volume to the desired level by sliding the ringer HIGH/LOW switch.



Krown Manufacturing, Inc.

3408 Indale Rd, Fort Worth, TX 76116

Voice: (817) 738-2485

TTY: (817) 738-8993

Fax: (817) 738-1970

E-mail: info@KrownMfg.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>