

Edger Blades

The Alroh edger cuts the grass with a clean knife like action. Adjustment of the blade depth can give a perfect finish without overloading the engine.

Reversing the blade can extend the blade life and ensure a good clean finish. The cutting tip speed of the blade reduces as the blade wears shorter and early replacement ensures the optimum performance.

Wire blade assemblies are available for edging soft paving or easily damaged edges.

Operation

To follow lawn contours or around obstacles, raise the edger handle slightly so as to run only on the front wheels. Move forward at a speed that gives you the best finish.

Service Record

Model Number		Serial Number	
Date Purchased		First Service	
1st Year Service		2nd Year Service	
3rd Year Service		4th Year Service	
5th Year Service		6th Year Service	

Your Local Alroh Dealer



RESIDENTIAL LAWN EDGER OWNER'S MANUAL



Manufactured by M.E.Y. Equipment
200 Collier Road, Bayswater WA 6053
Tel 08 9370 1110 Fax 08 9370 2566
www.alroh.com.au

Established 1951



ALROH EDGER

CONTROLS & BENEFITS



Congratulations

Thank you for buying a quality designed and manufactured Australian made product. Before operating the edger, we recommend that you read this operating guide and the engine manual. **THINK SAFETY AT ALL TIMES!**

- Know your machine & read these instructions.
- Keep hands & feet clear of the blades & moving parts.
- Learn how to stop the edger in event of an emergency.
- Check your lawn is free of obstructions, stones, metal or other items likely to damage the blades.

Maintenance

Alroh Residential Edgers are all fitted with sealed bearings to give a long maintenance free performance.

Avoid using a hose or pressure washer to clean the edger as this may force water into the bearings and engine.

Follow the engine manufacturer's recommendations for regular maintenance.

Avoid tipping the edger backwards or on its side either in transit or for service as this may allow the engine oil to pass into the cylinder head, carburettor and exhaust.

Starting Procedure

- Prior to starting, check oil and fuel levels. We recommend plain unleaded petrol rather than Premium be used.
- Turn the fuel and engine switch to the on positions.
- Check that the blade is fully secured by the blade nut.
- Check that the edger blade is fully lifted above the ground.
- The choke may need to be engaged for the first start.
- Set the throttle lever to a medium speed (half way).
- Pull the recoil starter in a smooth motion and avoid reaching the limit of the rope. Return the handle to the start position before releasing it.
- Once started, disengage the choke and adjust the engine revs to allow smooth operation of the clutch controls.
- Use the height adjuster lever to obtain the best cutting level for your turf conditions.

Stopping Procedure

- Lift the edger cutter blade.
- Turn the engine stop switch to the off position.
- If this fails to stop the engine, engaging the choke will normally stop the engine or by removing the spark plug lead.
- Always stop the engine before working on the edger.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>