






REMOTE CONTROL

Inserting batteries



1. Open the battery cover as shown below.



2. Insert batteries into the remote control.



3. Close the battery cover as shown below.




QWERTY Side - Front



- (POWER)** Turn the TV on or off.
- HOME** Access the homescreen.
- Navigation Buttons** (up/down/left/right) Move focus
- BACK** Move to previous or superior step.
- INPUT** Selects input list.
- VOICE** Searching by voice.
- OK** Select item by pushing key.
- Wheel** Spin the wheel up/down to scroll up/down.
- GUIDE** Access the EPG on connected set-top box. (Available only on Live TV)
- + VOL -** Adjust the volume level.
- ^ CH v** Change TV channels.
- Menu** Call option pop-up for activating app.
- Pointer** Activate/deactivate the pointer
- Gesture** Zoom in/out(Press and Hold)
- Mute** Mute all sounds.
- 3D** Change between 2D and 3D mode.(Press and Hold)
- Trick play keys** rewind, play, pause, fast forward


QWERTY Side - Back



- ESC** Cancel state or command
- Tab** Move focus to the next step
- Shift** Combination key for upper letter
- Back** Move to previous or superior step.
- EXT PWR (Fn+Z)** Turn on/off external device
- AMP PWR (Fn+X)** Turn on/off amplifier
- Enter** Finish text input
- Fn** Combination key with other keys
- Ctrl** Combination key with other keys
- Space** Enter a space
- TV** Activate TV player app
- PIP** Activate/Deactivate PIP
- INFO** Show channel information (available only on Live TV)
- DVR** Enter DVR menu
- AMP VOL - (Fn+←)/AMP VOL + (Fn+→)** Volume up/down on audio receiver

Quick Setup Guide

How to pair the remote control



Press the Pointer button to pair the remote control.

How to use the zoom in/out gestures



1. Press and hold the Gesture button for 2 seconds.
2. While holding the Gesture button, draw a circle in a clockwise direction to zoom in or counter-clockwise direction to zoom out. (This feature is only available in the Chrome browser.)

For more information


Refer to manual or go to www.lg.com

CONNECTIONS

IR BLASTER SETTINGS

HOME

The Setup Wizard will begin when you turn on the TV for the first time. You can connect the LG remote to a cable/satellite box by following the steps shown below.



- 1 Connecting to a network**
Connect the TV to a router with a LAN cable. Or connect with Wi-Fi by accessing Network Setup in the initial Setup Wizard. For seamless internet streaming LG recommends a stable 4Mbps broadband speed and 1.5Mbps as a minimum.
- 2 Connecting the cable/satellite box**
Use the appropriate cable that is provided from your cable or satellite provider to connect the cable/satellite box to the TV. Place the IR Blaster near the remote sensor.
- 3 Connect other devices**
Connect the Audio amplifier and other devices to the TV if necessary.




You can see the screen shown above to start the set up routine. There, select (A) to access the IR blaster settings.




Select the correct port that is connected to the cable/satellite box. You should see a TV signal once the correct port is selected.



Select your connected device type.



Select your lineup provider from the list. A TV signal should appear once you pick the correct provider.




Select the correct cable/satellite box manufacturer.




Check if the IR Blaster is firmly plugged into the IR Blaster port and is placed near the remote sensor of your device as shown above.



The TV will generate a test code to see if the remote is properly working with the cable/satellite box. Press the CH up and down to check the code. If the Channel doesn't change, then select [No, try next code] to repeat this step until you find right code.




The TV will generate a list of premium channels. Select [Yes] if you receive any of these channels.



Your channels are analyzed. If it is finished successfully. Select [Next].




Your LG remote is now set up to your cable/satellite box. You can now access the channel guide or connected set-top box with your remote.



* Please note that you need to have a Google account to setup the TV. It makes it more convenient to use Google's services and automatically restores your personal apps after a software update.

PRIMETIME QUICK GUIDE

The new quick guide makes it easy to find live TV content well organized in categories (Movies, Drama, Sports, etc.). Press the guide key anytime to bring up the best live TV content to you immediately.



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>