


LifeFitness

Elevation Cross-trainer 95X-ALLXX-01



Customer Support Services PARTS MANUAL rev 21 Oct 2008

Miscellaneous	3
Consoles	4
Back Console Cover and Console Support Bracket	5
Collar Covers and Dead Shaft End Caps.....	6
Bullhorns and Handlebars	7
Monocolumn and Deadshaft	8
Swoosh Covers and Stabilizer Assemblies	9
Rocker Arms and Front Clevis Covers	10
Pedal Levers	11
Frame Cover and Rocking Links	12
Rocker Assembly Covers.....	13
Rocker Assembly Components.....	14
Rear Tower Covers	15
Battery, GBC, and Poly-V Belt	16
Upper Tower Components	17
Cables.....	18

Description	Part No.
OPERATION MANUAL - (ENG)	M051-00K69-A002
(For units equipped with 15" LCD consoles only)+36V POWER SUPPLY LINE CORD DOM 10A, 125V LINE CORD CONT 10A, 250V LINE CORD U.K. 10A LINE CORD AUSTRALIA LINE CORD CHINA 10A, 250V	0017-00003-1037 0017-00003-0704 0017-00003-0691 0017-00003-0889 0017-00003-0918 0017-00003-1012
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
BRKT ASSY: POWER/COAX INPUT ASSEMBLY CONSISTS OF: 1) POWER COAX BRACKET 2) F-TYPE PANEL CONNECTOR 3) CAT-5 RECEPTACLE	AK66-00036-0000 0K66-01063-0000 0017-00021-2846 0017-00021-2980
HARDWARE BAG	AK69-00136-0000



7-inch Inspire LCD console



15-inch Engage LCD console




Achieve LED console

Not Shown
Console Support Bracket
AK69-00081-0000


Console Mounting Screws (4)
0017-00101-1972


Upper Back Cover
OK69-01126-0000




Back Console Cover
OK69-01122-0000
Mounting Screws (2)
0017-00101-1796

Back Cover Assembly
AK69-00115-0000










Power/Coax Input Bracket Assembly
(see page 3)
AK66-00036-0000


Monocolumn Assembly
AK69-00111-0000
Mounting Bolts (6)
0017-00101-1931
Washers (6)
0017-00104-0469




Dead Shaft
OK69-01002-0000
Mounting Bolts (2)
0017-00101-1925
Washers (2)
0017-00104-0469











Main Frame Cover
OK69-01132-0000
Mounting Screw (2)
0017-00101-1986

Rocking Link Cover
(right and left)
OK69-01119-0000
Link Cover Mounting Screw
0017-00101-1940

Lower Left Rocking Link Assembly
AK69-00113-0000
Front Rocking Link Mounting Screw
0017-00101-1904
Washer
0017-00104-0409
Front Spacer
OK69-01079-0000
Rear Rocking Link Mounting Screw
0017-00101-2023
Rear Spacer
OK69-01178-0000




Lower Right Rocking Link Assembly
AK69-00112-0000





Upper Rocker Cover
(left and right)
OK69-01108-0000
Upper Rocker Cover Mounting Screws (5)
0017-00101-1796


Outside Crank Cover with Decal
(left and right)
AK69-00096-0000
Outside Crank Cover Mounting Screws (2)
0017-00101-1988


Lower Rocker Cover
(left and right)
OK69-01109-0000
Lower Rocker Cover Mounting Screws (6)
0017-0010-1796











Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>