



TR97 Treadmill
General Assembly

TR97-0100-03
S/N HTP100000



TR97 Treadmill Frame Assembly Components

TR97-0100-03
S/N HTP100000



TR97 Treadmill Console (External View)

TR97-0100-03
S/N HTP100000

- Console Assembly
- AK58-00055-0001 Eng/Met
 - AK58-00055-0003 Ger/Met
 - AK58-00055-0004 Spn/Met/Eur (120v/60Hz)
 - AK58-00055-0005 Spn/Met (230v/50Hz)
 - AK58-00055-0006 Jap/Met
 - AK58-00055-0007 Frn/Met/Eur (120v/60Hz)
 - AK58-00055-0008 Itl/Met
 - AK58-00055-0009 Dut/Met
 - AK58-00055-0010 Por/Met
 - AK58-00055-0011 Frn/Met (230v/50Hz)

Front Console Shell Only
OK58-01008-0001


- Zone Training Overlay
- OK58-01215-0001 Eng/Met
 - OK58-01215-0003 Ger/Met
 - OK58-01215-0004 Spn/Met/Eur
 - OK58-01215-0006 Jap/Met
 - OK58-01215-0007 Frn/Met/Eur
 - OK58-01215-0008 Itl/Met
 - OK58-01215-0009 Dut/Met
 - OK58-01215-0010 Por/Met

- Workout Profiles
- OK58-01216-0001 Eng/Met
 - OK58-01216-0003 Ger/Met
 - OK58-01216-0004 Spn/Met/Eur
 - OK58-01216-0006 Jap/Met
 - OK58-01216-0007 Frn/Met/Eur
 - OK58-01216-0008 Itl/Met
 - OK58-01216-0009 Dut/Met
 - OK58-01216-0010 Por/Met

Stop Key w/Tether
AK58-00091-0000


Stop Switch Assembly
Gk58-00002-0007

- Tray/Switch w/Overlay Assy
- AK58-00061-0001 Eng/Met
 - AK58-00061-0003 Ger/Met
 - AK58-00061-0004 Spn/Met/Eur
 - AK58-00061-0006 Jap/Met
 - AK58-00061-0007 Frn/Met/Eur
 - AK58-00061-0008 Itl/Met
 - AK58-00061-0009 Dut/Met
 - AK58-00061-0010 Por/Met



Rear Console Decal
OK58-01129-0000


Rear Console
OK58-01009-0000



Phillips Screw-4
(8-32x6)
0017-00101-0776

Phillips Screw-8
(10-32x8)
0017-00101-1288


- Switch Cover
w/Tether
AK58-00096-0000
- Cover Only
OK58-01087-0000
- Anchor Washer
OK58-01158-0000



Stop Key w/Tether
AK58-00091-0000


**TR97 Treadmill
Console (Internal View)**

**TR97-0100-03
S/N HTP100000**





TR97 Treadmill
Cover, End Caps, Hardware

TR97-0100-03
S/N HTP100000



TR97 Treadmill
Belt, Deck, Rear Roller


TR97-0100-03
S/N HTP100000



IMPORTANT: Components can be ordered separately with Serial Numbers above:
 TR9100 HTN102105-Above, TR9500 HTM105585-Above, and TR9700 HTP100531-Above.
 Use the appropriate Roller Guard Kit: GK58-00002-0056 for TR91/95, and GK58-00002-0057 for Tr97 with
 Serial Numbers: TR9100 HTN102105-Below, TR9500 HTM105585-Below, and TR9700 HTP100531-Below.


TR97 Treadmill
Lift Motor and Lift Frame

TR97-0100-03
S/N HTP100000



**TR97 Treadmill
Power Box Assembly**


**TR97-0100-03
S/N HTP100000**






TR97 Treadmill Motor Controller

TR97-0100-03
S/N HTP100000

Wax Lift / Motor Controller
AK58-00164-0001 120v
AK58-00164-0002 230








**TR97 Treadmill
Idler Arm Assembly**

**TR97-0100-03
S/N HTP100000**



TR97 Treadmill
Lever Assembly – AK58-00076-0000

TR97-0100-03
S/N HTP100000


Flat Washer-4
0017-00104-0190

Assembly Leveler & Bushing
AK58-00089-0000

Lock Washer-4
0017-00104-0333


Hex Nut-4
(8-18x10)
0017-00101-1253

Pivot Pin
OK58-01098-0001




Stop Nut
OK58-01099-0000


Leveling Foot
OK58-01110-0000




TR97 Treadmill
Front Roller Assembly – AK58-00067-0000


TR97-0100-03
S/N HTP100000








Message Center Console



WAX LIFT POWER SUPPLY



Power Modules

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>