


Part # AD-Element 3W

211101



## Part List

- 1 Element Touch Lamp (A)
- 1 Power Adaptor (B)

## Instructions

1. Remove Element Touch Lamp from carton.
2. Place unit on a sturdy, leveled surface.
3. Attach Adaptor jack (B) to Element Touch Lamp base (A) and plug into power outlet.
4. Touch lamp to operate ON/OFF.

## Caution

1. Never operate this appliance if it has a damaged cord, plug or cable.
2. Use the provided adaptor only.
3. Keep cord away from heated areas.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>