ICE CUBERS T ICE DISPENSERS T ICE STORAGE BINS REACH-IN REFRIGERATORS & FREEZERS

ISO 9001 Quality System Certified

7620283 R12 400 SERIES, 50 HZ. COMPRESSOR REPLACEMENT INSTRUCTIONS

- 1. Remove old compressor. Unsweat all tubes from the old compressor. Do not cut them off.
- 2. Remove the start capacitor.
- 3. Remove the start relay.

Note: If the old compressor was a Copeland model:

- · Cut 2" off of the suction line.
- · Remove the three compressor leads from the ice machine.
- Remove the two remaining leads from the start relay from the ice machine.
- · Install six new wires (included in kit) following wiring diagram (included in kit).
- 4. Assemble the new start relay to the mounting bracket and mount it in the control box.
- 5. Mount the new start capacitor to the existing bracket.
- 6. Install the new compressor, as shown. If the old compressor was a Copeland model, follow the assembly sketch below.

- 7. Replace filter drier with new one. Check your Manitowoc parts manual for correct drier size.
- 8. Wire all components according to the wiring diagram included in this kit.
- 9. Place new wiring diagram on top of old one.
- 10. Evacuate the ice machine following the steps on the Service Bulletin.
- 11. Charge the ice machine with the nameplate charge.

8003413 Revised 11/15/95

MANITOWOC EQUIPMENT WORKS

Division of The Manitowoc Company, Inc. I 2110 South 26th Street, P.O. Box 1720, Manitowoc, WI 54221-1720 U.S.A. (414-682-0161 | FAX 414-683-7879

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com