

ET0100 THE ILLUMINATOR

Wind up:


1. Lift handle into the open position
2. Wind handle in clockwise direction for 30-60 seconds to charge
3. Return handle to closed position
4. Press button repeatedly to change light intensity

Notes:

- Avoid pointing light directly in eyes
- Do not submerge light in liquid
- Wind steadily in a clockwise direction

Suggestion:

For best results, wind up to 10 minutes before first use.



Mark Feldstein & Associates
www.markfeldstein.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>