

# REMOTE CONTROLS

Infrared extension and Home Control



*Special assortment of universal remote controls.*

*Control more appliances than before and from a greater distance.*

*Ready for the future.*

**MARMITEK**

	EasyControl 4	EasyControl 6	EasyControl 8	EasyTouch 25	EasyTouch 35	PC Control
TV • VIDEO • SAT • DVD	•	•	•	•	•	•
DECODER / SETTOP BOX		•	•	•	•	•
AUDIO • STEREO • CD		•	•	•	•	
PC • SHOWSHIFTER						•
TELETEXT / FASTTEXT / MENU	•	•	•	•	•	
SHOWVIEW • VCR TIMER		•	•	•	•	
ACTIVE SOURCE INDICATOR			• ①	• ②	• ②	
TOUCHSCREEN ②				•	•	
UPDATE (LEARN) ③		150 keys	150 keys	240 keys	320 keys	
HOME THEATRE MACROS ④		3x	3x	9x	9x	
 CONTROL ANYWHERE ⑤			•		•	•
 HOME CONTROL ⑥			•		•	•

All Marmitek remote controls contain a very extensive library for standard control of almost any appliance. Depending on the model they also feature a number of special attributes such as those listed below.


**① ACTIVE SOURCE INDICATOR**

Know which appliance you control: pressing a random button activates a red LED on the appliance selected.



**② TOUCHSCREEN**

- Only the functions for the appliance selected appear on the screen.
- Can be configured to your own preferences.
- Light blue screen lighting.




**③ UPDATE/LEARN**

Programming button for learning functions from the original remote control. This also works for appliances that you will buy in the future.




**④ HOME THEATRE MACRO**

By pressing the Macro button you can control a series of pre-programmed appliances and devices (for example in Home Theatre applications: TV on and tuning of Audio/Video channels, turning on a DVD player, turning on a surround sound system, dimming lights, closing curtains).



**⑤ CONTROL ANYWHERE**

Suitable to control appliances that are out of sight, at a great distance or even in other rooms in the home. Works in combination with Marmitek remote controls with a RF (radio frequency) transmitter.



**⑥ HOME CONTROL**

The Home Control TM13 has a double functionality: Firstly it is a ON/OFF switch for electrical appliances. It is also the starting point and central device of the Marmitek Home Control Programme and works as a converter that transmits signals via the mains. Lights and electrical appliances (such as an extractor fan or water fountain) can be controlled from anywhere in the house. Works in combination with Marmitek remote controls with a RF (radio frequency) transmitter.

**ORDERING INFORMATION**

- EasyControl 4 Art. no. 09660
- EasyControl 6 Art. no. 09661
- EasyControl 8 Art. no. 09662
- EasyTouch 25 Art. no. 09663
- EasyTouch 35 Art. no. 09664
- PC Control Art. no. 09645
- Control Anywhere (EU) Art. no. 09665
- Control Anywhere (U) Art. no. 09674
- Home Control TM13 (G) Art. no. 09666
- Home Control TM13 (F) Art. no. 09674
- Home Control TM13 (U) Art. no. 09675
- Home Control TM13 (I) Art. no. 09676
- Home Control TM13 (CH) Art. no. 09677



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>