


Barbie®
B5766








Christie®
B5767




Summer®
C6789



Contents include (1) doll pictured above and all of the accessories shown below.



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.








CONTENTS

Please remove everything from the package and compare to the contents shown here. Keep these instructions for future reference as they contain important information. If any items are missing, please call 1-800-524-TOYS.

Dolls sold separately. Subject to availability. Fashions, colors and decorations may vary.
Dolls cannot stand alone.


ADULTS NOTE: Cut the plastic attachment with safety scissors and discard pieces.

Assembly




Play Time!

Water toys sometimes get messy. Protect play surfaces before use. Do not use on surfaces that can be damaged by water. Dry all items thoroughly before storing.




1 Load earring (TOP first). Push earring all the way in until it stops.



2 Fill cup with **icy cold** water then pour water into bottle

Cup not included.




3 Dampen a cotton ball.

4 Wipe **icy cold** cotton ball across doll's ear.



LOOK! 3 darker plugged "holes" appear where you may "pierce" doll's ears.

There are 3 "plugged holes" on each ear.
After each hole has been "pierced", it will not color change with icy cold water again.




IMPORTANT! Color changes will last longer if you **DO NOT** expose doll to intense heat or direct sunlight for prolonged periods of time.

HELPFUL TIP: The colder the water, the better the "holes" show.



5 Place tip of earring on top of "hole" and push earring into doll's head. Squeeze applicator all the way and then release.




One, two, or three holes per ear!





6 Pull applicator away.
Doll's earring is attached.


Add a dangle too!



1 Load earring (TOP first). Push earring all the way in until it stops.



NOTE: Insert dangles into the **BOTTOM** hole.



Pull out to remove earrings.

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-665-6288.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303.

Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China

Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

Mattel, Inc., El Segundo, CA 90245 U.S.A. Consumer Affairs 1 (800) 524-Toys.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>