

## MA188 FM Transmitter/MP3 Player Instruction Manual

1. Insert the MA188 into your vehicle's 12V power outlet ( in some vehicles this is the cigarette lighter)
2. Connect your USB thumb drive or MP3 player to the unit's USB jack (see picture below).
3. Press and release the ►/II (play/pause) key, and the **"POWER"** light will then flash. This means the unit is on and you can now play music through the unit.
4. Press and release the ►/II key again and the **"POWER"** light will remain on (solid) – this means the unit is now paused.
5. Press the I◀◀ key and hold to increase the volume; and press it and release to return to the last song. Press ►►I key and hold to decrease the volume; press and release it to skip to the next song.
6. To change the FM station that the unit transmits on: Press the **"F"** key for three seconds, the **"FM Light"** will start to flash indicating which transmitting station you are on. Repeatedly press the **"F"** key to change to the next transmitting station. When the last station has been reached, the unit will start back again at the first station.
7. There are 7 transmitting stations: FM87.7, FM87.9 FM88.1, FM88.3, FM88.5, FM88.7 and FM88.9.

PUT UNIT DRAWING HERE

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>