


Assembly Instructions for HTS2 Speaker Stand



STEP 1:

Place speaker stand base(a) upside down on ground and thread steel isolation spikes in the 3 holes. Turn the base over (isolation spikes can scratch floors, use caution) and thread the outer post(b) into the hole in the base. See Fig. 1





STEP 2:

Select Appropriate speaker adapter (Fig. 2) for your particular speaker application. If your speaker comes with a threaded insert use bracket g, h, or j. If your speaker does not come with a threaded insert you will need to use the clamping mechanism (f). For clamping mechanism see STEP 3.1.

STEP 3: Adapter Brackets

Attach the adapter to the inner post(d) using the 5 mm mounting screw(e), then attach the speaker to the selected bracket using provided hardware and set to desired height.

STEP 3.1: Clamping Mechanism


Attach top plate and inner post(d) with mounting screw(e) (see fig 4). loosen the wing nut from the side rails just enough for the side rails to move left and right freely(see fig 5). Move the right side rail all the way to the right and the left side rail all the way to the left. Peel back the paper on the foam dampening pads so the adhesive is exposed, then place the dampening pad on the inside of the right and left side rails (see fig 6). Place the speaker so it is centered on the top plate (for extra security you may use the provided hook and loop tabs) Download from Www.Somanuals.com. All Manuals Search And Download.

the foam dampening pads fit snugly against the speaker(see fig 7). Before tightening wing nuts make sure the speaker is centered on the top plate and there is equal distance from the top plate to the right and left side rails(see figure 7). Now secure the the side rails by tightening the wing nuts.

STEP 3.2: Keyhole Bracket

Use the #8 machine screw and the #8c nut to attach the speaker as shown. The circular nut fits through the speakers keyhole slot. If the end of the screw touches the speakers inside surface, use the

#8h nut as a spacer, see fig 8.



STEP 4:

Tighten threaded set screw into hole in the side of outer post(b). See Fig. 3

STEP 5:

Route speaker wires through the hole in the back top of inner post(d) and out the bottom of the base.

OmniMount claims no liability for misinterpretations of these instructions, or damage caused by user error.



Home Entertainment

For assistance or more information on other great products from OmniMount Systems, Inc. contact us at:

OmniMount Systems, Inc.
The Pointe at South Mountain
8201 S. 48th St.
Phoenix, AZ 85044-5302
1-800-MOUNT-IT!

voice: 480-829-8000 fax: 480-756-9000 web: www.omnimount.com



HTS2 SPEAKER STAND



ADAPTABILITY

COMES WITH THREE INTERCHANGEABLE. ADAPTERS AND CLAMPING MECHANISM.

CABLE MANAGEMENT

HIDE UNSIGHTLY WIRING THROUGH POST.

QUALITY

BUILT WITH POWDER COATED STEEL.

FLEXIBILITY

SEAMLESS APPEARANCE AND HEIGHT ADJUSTMENT.

STABILITY

THREE TOUCH POINTS FOR THE ULTIMATE IN STABILITY.









M ALL PARTS

© 2003 OmniMount Systems, Inc. All rights reserved. OmniMount is a registered trademark of OmniMount Systems, Inc.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com