





- English Instruction Manual
- Deutsch Bedienungsanleitung
- Français Mode d'emploi
- Español Guía del usuario
- Português Manual de instruções
- Italiano Istruzioni per l'uso
- Nederlands Gebruiksaanwijzing
- Dansk Brugsanvisning
- Norsk Bruksanvisning

- Sverige Bruksanvisning
- Suomi Käyttöohje
- Ελληνικά Οδηγίες χρήσεως
- Русский Инструкция пользователя
- Türkçe Kullanım kılavuzu
- Polski Instrukcja obsługi
- Česky Návod k použití
- Magyar Használati útmutató









SV-9352

Frequency	Channel	Imped	No. of elements	Gain	Front-back ratio	Beam width Honz/vertical	Length
470~862 MHz	21-69	75Ω	47	11-12 dB	24dB	H30° - 50° / V35° - 55°	1282mm

Universal Electronics BV
Europe & International
P.O. Box 3332
7500 DH, Enschede
The Netherlands



SV-9352
706224
RDN 1180108



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>