Panasonic

IP Proprietary Telephone

Quick Reference Guide

Model No. KX-NT265

Important Information

When using the KX-NT265, keep the following conditions in mind.

- If the unit does not operate properly, disconnect the unit from the Ethernet[®] cable and then connect again.
- If you are having problems making calls, unplug the Ethernet cable and connect a known working IP Proprietary Telephone (IP-PT). If the known working IP-PT operates properly, have the defective IP-PT repaired by an authorised Panasonic Factory Service Centre. If the known working IP-PT does not operate properly, check the Hybrid IP-PBX and the Ethernet cable.
- Wipe the unit with a soft cloth. Do not clean the unit with abrasive powders or with chemical agents such as benzene or thinner.
- Use only the correct Panasonic handset.
- Do not disassemble this unit. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians.
- If damage to the unit exposes any internal parts, immediately disconnect the cable or cord. If the
 power is supplied from the network to the IP-PT [Power-over-Ethernet], disconnect the Ethernet
 cable. Otherwise, disconnect the AC adaptor cord. Then return this unit to a service centre.
- Never attempt to insert wires, pins, etc. into the vents or other holes of this unit.
- This unit is designed to aid the visually handicapped to locate dial keys and buttons.
- This unit is designed to be installed under controlled conditions of ambient temperature and a relative humidity.
- Avoid installing the unit in damp or humid environments, such as bathrooms or swimming pools.
- 999 and 112 can be dialled on the product after accessing the CO line for the purpose of making outgoing calls to the BT emergency (999) and (112) services (United Kingdom only).

Take special care to follow the safety suggestions listed below. Safety

- The unit should only be connected to a power supply of the type described in the Quick Reference Guide or as shown on the label on the unit.
- 2) When left unused for a long period of time, the optional AC adaptor should be unplugged from the AC outlet, if you are using Power-over-Ethernet, disconnect the Ethernet cable.

Installation

Environment

- Do not use this unit near water, for example, near a bathtub, washbowl or sink. Damp basements should also be avoided.
- 2) Keep the unit away from heating appliances and devices that generate electrical noise, such as fluorescent lamps, motors and televisions. These noise sources can interfere with the performance of the unit. It also should not be placed in rooms where the temperature is less than 5 °C or greater than 40 °C.

Placement

- 1) Do not place heavy objects on top of this unit.
- 2) Care should be taken so that objects do not fall onto, and liquids are not spilled into, the unit. Do not subject this unit to excessive smoke, dust, moisture, mechanical vibration, shock or direct sunlight.
- 3) Place the unit on a flat surface.

Important Information

WARNING:

TO PREVENT POSSIBLE FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

THIS HANDSET EARPIECE IS MAGNETISED AND MAY RETAIN SMALL FERROUS OBJECTS.

UNPLUG THIS UNIT FROM POWER OUTLET/THE ETHERNET CABLE IF IT EMITS SMOKE, AN ABNORMAL SMELL OR MAKES UNUSUAL NOISE.

THESE CONDITIONS CAN CAUSE FIRE OR ELECTRIC SHOCK. CONFIRM THAT SMOKE HAS STOPPED AND CONTACT AN AUTHORISED SERVICE CENTRE.

IMPORTANT NOTICE:

- Under power failure conditions, the IP-PT may not operate. Please ensure that a separate telephone, not dependent on local power, is available for use in remote sites in case of emergency.
- For information regarding network setup of the IP-PT such as IP address, please refer to the Installation Manual for the Panasonic Hybrid IP-PBX.
- If an error message is shown on your display, consult the network administrator.
- The firmware of the KX-NT265 is protected by copyright laws and international treaty provisions, and all other applicable laws. It can not be reverse engineered, decompiled or disassembled.

This unit is capable of being used in conjunction with hearing aids fitted with inductive coil pick-ups. The handset should be held as for normal conversation. For operation, the hearing aid should be set to its "T" position or as directed in the operating instructions for the hearing aid.

Note:

In this manual, the suffix of each model number is omitted.

Trademark:

Ethernet is either a registered trademark or a trademark of Xerox Corporation in the United States and/or other countries.

This model supports the following PBX and IP-EXT card versions:

KX-TDA100/KX-TDA200: PMPR Software File Version 3.0000 or later

KX-TDA600: PLMPR Software File Version 3.0000 or later

KX-TDA0470(IP-EXT16): PIPEXT Software Version 1.001 or later/

PVOIPEX Software Version 1.011 or later


Outside (CO) Line bu	tton D Off-hook			
(ICD Group) Incoming Call Distr	ibution Group button	(DSS) Direct	Station Selection buttor	1
C. Tone Confirmation Tone	Ringback To	ne		

Feature	Operation						
	Making Calls						
Calling	To an extension To an outside party extension no. ► (((-)) ((CO)) To an outside phone no. ► (((-)) ((CO)) To an outside phone no. ► (((-))						
Redial	> ► REDIAL ► GUÉ						
Quick Dialling	Parameter (1/2) Quick dial no. Quick dial						
One-touch Dialling	To store PROGRAM (co) To dial assigned as a One-touch AUTO DIAL PROGRAM STORE PROGRAM O AUTO DIAL PROGRAM O O O O O O O O O O O O O						
Operator Call	Dialling button						
Personal Speed Dialling	To store ★ 3 0 personal speed desired no. (max. 32 digits) # C. Tone						
System Speed Dialling	To dial AUTO DIAL System speed dial no. (3 digits) F(4) (4) System speed dial no. (3 digits)						
Doorphone Call	★ 3 1 ► doorphone no. (2 digits)						
Automatic Callback Busy	To set While hearing a busy tone C. Tone To answer from an idle extension While hearing a callback ring R.B. Tone To cancel X 4 6 C. Tone To answer from an idle outside line While hearing a callback ring To utside phone no. In the cancel To cancel To answer from an idle outside line While hearing a callback ring To utside phone no.						
	During a Conversation						
Call Hold	To hold To retrieve a call at the holding extension						

Feature	Operation					
	During a Conversation					
Call Transfer	TRANSFER C. Tone Extension no. To an extension Outside phone no. To an outside party To an outside party					
Useful Features						
Off-hook Monitor	To set/cancel During a conversation using the handset					
Call Park	To set TRANSFER					
	To retrieve stored parking zone no. (2 digits) C. Tone (4)					
Multiple Party Conversation	To add other parties during a conversation assigned as a CONFERENCE button C. Tone button C. Tone parties. Talk to the new party. To leave a conference assigned as a CONFERENCE button C. Tone assigned as a CONFERENCE button C. Tone Talk with multiple parties.					
Call Pickup	Extension no. Directed ★ 4 1 ► extension no. Directed ★ 4 0 ► group no. (2 digits) Group C. Tone					
Sending a Call Waiting Tone	While hearing a busy tone 1 ▶ Wait for an answer. ▶ \$\(\bigg _{\((\lambda \) \chi \)}\)					
Answering a Call Waiting	To hold the current call then talk to the new party HOLD					

^{*} Disregard this step if both parties are extensions.


Feature	Operation				
	Useful Features				
Paging	To page Paging group Paging group group Paging group Paging group Paging group group group Paging group gro				
Message Waiting	Caller To leave a message waiting indication When the called extension is busy or does not answer MESSAGE C. Tone To call back extension To call back MESSAGE MESSAGE MESSAGE MESSAGE				
Log-in/Log-out	* 7 3 6 1 For Log-in CD Group extension no. Specified extension no. All C. Tone				
	Before Leaving Your Desk				
Setting Absent Message	To set				
Call Forwarding	Busy/ No answer Description Both Calls Outside Calls Intercom Calls Extension no. Coline access no. Coline phone no. Coline access no. Co				





- Consult your dealer for more details about the feature numbers.
- You can change the flexible CO buttons to the feature buttons.
- "Location of Controls" is shown on page 7.

Location of Controls



- 1 LCD (Liquid Crystal Display)
- **2 PROGRAM:** Used to enter and exit the personal programming mode.
- **3 TRANSFER:** Used to transfer a call to another party.
- INTERCOM: Used to make or receive intercom calls.
- **6 VOLUME Control Button:** Used to adjust the volume.
- 6 AUTO ANS (Auto Answer)/MUTE: Used to receive an incoming call in hands-free mode or mute the microphone/handset during a conversation.

- **AUTO DIAL/STORE:** Used for System/Personal Speed Dialling or storing programme changes.
- Headset Jack
- REDIAL: Used to redial the last dialled number.
- FLASH/RECALL: Used to disconnect the current call and make another call without hanging up.
- **1** HOLD: Used to place a call on hold.
- Microphone: Used for the hands-free conversation.
- SP-PHONE (Speakerphone): Used for the hands-free operation.
- Flexible Outside (CO) Line Buttons: Used to make or receive an outside call. Pressing this button seizes an idle outside line automatically. (Button assignment is required.) Also used as feature buttons. (Button assignment is required.)
- MESSAGE: Used to leave a message waiting indication or call back the party who left the message waiting indication.
- Message/Ringer Lamp: When you receive a call, the lamp flashes red. When someone has left you a message, the lamp stays on red.

♦♦ Setting


Ringer volume

While on-hook or receiving a call

(a) (7)

Press UP or DOWN.

Ring Tone



* The ring tone pattern of patterns 09 to 30 is the same as pattern 01.

◆LCD Contrast/Headset Mode




Settings on the Programming Mode

To enter the programme mode			To exit					
PROGRAM				PROGRAM				
	Operation							
Loop-CO (L-CO)	AUTO DIAI				FWD/DND - Both calls	⇔ (4 1 •	AUTO DIAL
Single-CO (S-CO)		0 CO line	AUTO)	FWD/DND - Outside calls		4 2 >	AUTO DIAL STORE STORE
Direct Station Selection	" ►	1 extension	on AUTO STO.	DIAL DIAL RE	FWD/DND - Intercom calls	" ► (4 3 ▶	AUTO DIAL O STORE
One-touch Dialling	" ►	2 desired	no. AUTO STO.)	Account	"► (<u>4</u> (8) ▶	AUTO DIAL O STORE
Incoming Call Distribution	□ ►	3 0	AUTO_DIAL		Conference	" ► (4 9 >	AUTO DIAL STORE
Group (ICD Group)	▶ [10	D Group no.	► O STORE		Log-in/ Log-out	□ ► (5 5 >	AUTO DIAL O STORE
Preferred Line Assignment-Outgoing 1 9 AUTO DIAL An idle outside line A			AUTO DIAL NO STORE					
Preferred Line Assignment-Ind	coming	20	AUTO DIAL STORE	0 1 2	<u> </u>	- م مارچہ آ	No line The longest ringing line An assigned outside button	■ AUTO DIAL STORE
Alternate Receiving- Ring/Voice		2 1	AUTO DIAL STORE	① 〔1 〔2	Directly (Voice	•	AUTO DIAL STORE	
Call Waiting for Outside calls		30	► O DIAL STORE	No (No tone) / 1 Yes (Tone) ▶ $\bigcap_{STORE}^{AUTO\ DIAL}$			0	
Call Waiting Selection		31	► O DIAL STORE		No Call / 1 Tone/ 3 Whisper OHCA ► OSTORE			
			AUTO DIAL STORE					
Extension PIN [Personal Identification Number] (PIN-max.10 digits)		90	AUTO DIAL STORE	Exte	et an extension PI AUTO DIA ension PIN ► O store hange a stored extension PIN ► red extension PIN ► red	same Pl	_	N STORE
Station Prograi Data Default S		###	► O DIAL STORE	AUTO D STOR	<u>-</u>			


Tilt Angle

The tilt angle of the unit can be adjusted.

To adjust the angle, insert the stand into the desired holes as shown below.



Connection



Connection

*AC adaptor Order No.

United Kingdom: KX-A237E (PQLV1E)/Greece: KX-A237CE (PQLV1CE)

CAUTION:


The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is located near the unit and is easily accessible.

Note


Consult your dealer for more details about the AC adaptor.

Wall Mounting


1 Pull down the handset hook until it locks, so the tab holds the handset.




2 Remove the attached stand.




3 Mount the unit on the wall.



To temporarily place the handset down during a conversation, hook it over the top edge of the phone as shown.



Wall Mounting



Screw

Information

Information on Disposal for Users of Waste Electrical & Electronic Equipment (private households)



This symbol on the products and/or accompanying documents means that used electrical and electronic products should not be mixed with general household waste.

For proper treatment, recovery and recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis. Alternatively, in some countries you may be able to return your products to your local retailer upon the purchase of an equivalent new product.

Disposing of this product correctly will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise

arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

For business users in the European Union

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

Information on Disposal in other Countries outside the European Union

This symbol is only valid in the European Union.

If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.



This product is intended to be connected to a Panasonic Hybrid IP-PBX only. Panasonic Communications Company (U.K.) Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC. Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting: http://www.doc.panasonic.de

Contact:

Panasonic Services Europe a Division of Panasonic Marketing Europe GmbH Panasonic Testing Centre Winsbergring 15, 22525 Hamburg, Germany

Copyright:

This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

©2006 Panasonic Communications Co., Ltd. All Rights Reserved.

Panasonic Communications Company (U.K.) Ltd.

Pencarn Way, Duffryn, Newport, South Wales, NP10 8YE, United Kingdom

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com