

#### CAR FM RADIO

Adjust the frequency of car FM radio to the same one as transmitter for receiving signals.

④ To adjust car FM radio

# **P**i.PYLE

## PiFM7



### Car Stereo

### Wireless FM Transmitter

Transfer Your Music Into Your Car Radio




## SKETCH-MAP




## OPERATION

LCD will light when power on



Plug into car cigarette lighter socket

① To switch on power



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>