

## User's Manual



Before operating the Monitor, please read this manual thoroughly and retain it for future reference.

### MONITOR:

- 1.P. Power
- 2.+ . Positive
- 3.M. Menu
- 4.-. Negative
- 5.CH+. V1/V2 Change
- 6.CH-. Mode Change



### CAUTION:

For your safety, please rotate the angle of the display or turn off the display while driving.

### SPECIAL STATEMENT:


LCD may have a few bright dots, which is normal for the matrix display technology, and doesn't indicate defects of faults

### NOTICE:

- Please operate instruction manual completely before use ;
- The unit is manufactured with precision elements pay attention to protection against dampness;
- Prevent the hard object from scratching LCD surface;
- High voltage inside non-technical authorized person is not allowed to dismantle the unit.

### REMOTE CONTROL

1. Power
2. V1/V2 Change
3. Positive Increase
4. Menu
5. Negative Decrease
6. Mode Selection



### Connection



### SPECIFICATIONS:

- Display size : 10.2" , 7" & 5.6
- Dual video inputs
- PAL/NTSC Auto switching
- Power supply: DC + 12V
- All functions are controlled by remote control
- Anti-glare mirror
- Wide view angle

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>