
CIPYLE PiP30 Instruction



www.pyleaudio.com

FEATURES

- 1. Ipod special docking can connect directly with Ipod, Ipod mini, Ipod nano, Ipod video $2. \ Charging \ Ipod \ directly \ and \ prevent \ the \ Ipod \ from$ damage in the charge.
- 3. Ipod video output terminal outputs video signal to TV.
- 4. USB data transmission port can connect with computer to download data and charge.
- 3.5mm audio input jack can connect any audio device with 3.5mm audio output jack (e.g. MP3, MP4 etc.)
- 6. Digital amplifying technology supplies Hi-fi sound with high quality and extends battery life. 7. Output power is 40W×2.
- 8. Power supply: AA 1.5V×3 or AC adaptor.

IMPORTANT SAFETY INSTRUCTIONS

- 1. Read instructions-All the safety and operating instructions should be read before operation.
- Retain instructions-The operating instructions should be retained for future reference
 Follow instructions-All operating and use instructions should be followed.
- Location-The appliance should be installed in a stable location.
 Heat-The appliance should be situated away from heat source such as radiations, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- 6. Power sources-The appliance should be connected to a power supply only of the type described in the operating instructions or as marked in the appliance 7. Non-use Periods-The power cord of the appliance should be unplugged from the outlet when
- unused for a long time.
- Lighting storms-Unplug the apparatus during lighting storms.
 Object liquid entry-Care should be taken so that objects do not fall and liquids are not spiced into
- the enclosure through openings

 10. Damage requiring service-The appliance should be serviced by qualified service personal when:
 - the power-supply cord or the plug has been damaged. objects have fallen or liquid has been spilled into the appliance.

the appliance has been dropped or the enclosure damaged

the appliance has been exposed to rain. the appliance does not appear to operate normally or exhibits a marked change in performance.

PLACING THE PORTABLE SPEAKER

Placing the portable speaker system on alevel surface preferably close to you (with in three feet)

MAKING CONNECTIONS

WARNING:

Do not insert the speakersystem's universal power supply intowall outlet until all connections are made. Also turn off your Ipod before docking on the portable speak system

AC power-After your Ipod is docked on the portable speaker system, plug the universal power supply into a wall outlet. The speaker system is now ready to operate.

DC (battery) power-This portable speaker system can also be powered with three AAbatteries (not included).Install three AAbatteries (not included) into the battery compartment. Make sure the batteries are installed as illustrated in the battery compartment. After your lpod is docked on the portable speak system, the speaker system is ready to operate.

- 1. Play Ipod: If you want to output Ipod video to TV, firstly please turn on the TV output in video setting option. Then go ahead to play video.


 2. Press the volume button. The red LED lights.
- 3. Adjust the volume by pressing volume "+",volume"-"


To maximize battery life during battery-only operation, move power switch located on the back of the unit to the "off" position for power off.


SPECIFICATIONS:


Power Supply: 4.5V(AAAX3) or AC adaptor with 9V 1200mA Output Power: 40Wx2(1KHz 10% 7HD)

Speaker Size: 1.5"x3Wx2(4 \Omega)











Instruction:




① A. Install 3pcs AA batteries(not included) into battery compartment or use DC 9V adapter


B. turn on the power




③ Install the iPod




(5) Connect with TV by RCA cable for video output



6 Connect with Computer to download data



 ${\color{red} {\textcircled{2}}}$ Choose correct Ipod adaptor type.



(7) other audio device can be connected with portable speaker system by stereo cable insert to the socket "input"

4Start playing, adjust the volume

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com