

SPECIFICATIONS

Input impedance.....	1.5k Ohm
Output Voltage.....	2.1V Max
Maximum Gain.....	50dB
Power Source.....	DC 12V or 9V battery(not included)

Service for your Pyle Audio Product

(U.S.) Should your Pyle Audio Product require service, please contact the Pyle Service Department via telephone at (718) 236-8000 or email at service@pyleaudio.com

DO NOT ATTEMPT TO SERVICE THIS UNIT YOURSELF AS IT CAN BE DANGEROUS AND WILL ALSO VOID THE WARRANTY

PYLE[®]AUDIO

1600 63rd Street • Brooklyn, NY • 11204
718 535-1800 • Fax: 718 236-2400
www.pyleaudio.com

PYLE[®]
PRO

OWNER'S MANUAL



PDMX4L

4 CHANNEL MINI MIXER

Congratulations on your choice of the mini mixer. You have purchased one of the finest mini mixers on the market today. You will find that your new Pyle PDMX4L has superior performance and greater flexibility than any other mini mixer in its price range. Please read this manual carefully to get the most out of your new unit. Thanks for selecting Pyle Audio as your choice in mini mixers.

FEATURES


- Stereo/Mono Work Module, Controlled by Module Switch, 4 Unbalanced Input Channels & One Balanced Output Channel
- Separate Volume Control
- Total Gain 24dB
- Frequency Responsibility: 10Hz-100KHz
- Total Harmonic distortion less than 0.05%
- Max Output Level is +16dB (Balanced Output)
- Continuous Working (for More than 12 Hours)
- Powered with 9V Alkaline Battery or Optional AC/DC External Adapter(NOT INCLUDED)
- Dimensions: 5.91" x 3.94" x 2.36"

NOTICE

The Information in this document is subject to change, as the company may make changes to product in order to improve reliability, design or function, without prior written notice. No part of this manual may be reproduced or transmitted in any form or by any means without the written permission of the company.

IN NO EVENT WILL THE COMPANY BE LIABLE FOR SPECIAL INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING DIRECTLY OR INCIDENTALLY, SUCH AS LOSS OF PROFIT OR GOOD WILL, THAT MAY BE SUFFERED IN CONNECTION WITH THE PURCHASE OF THIS PRODUCT OR FROM THE BREACH OF ANY REPRESENTATION OR WARRANTY

FRONT PANEL CONTROL



1. Input level control.
2. Output level control.
3. Input jack.
4. Output jack.
5. Power switch.
6. Power indicator light

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>