




PPDLWW1

WAH WAH PEDAL

1. The SIGNAL OUTPUT is used to connect to the amplifier
2. The SIGNAL INPUT connects to the instrument
3. DC9V POWER PLUG can be used to power the pedal
4. The PEDAL is used to control the effect
5. ON/OFF switch
6. 9 Volt REPLACEABLE BATTERY



SPECIFICATIONS:

- Designed for Electronic Guitars
- Includes Instrumental and Amplifier 1/4" Ports
- Rubber Bottom Floor Grips
- Wah Wah Effects Pedal
- True Bypass Switch
- Includes 9V 6F22 replaceable battery
- Battery Life for Continuous Use: 100 Hours
- Dimensions: (L) 9 1/4" (W) 3 1/2" (H) 2 1/2"

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>