

Portable DVD Player


User manual
Manual d'utilisation
Manual de usuario

Need help? Call us!
Philips recommends you only help you with the questions about your product.



PHILIPS CONSUMER ELECTRONICS COMPANY

Marietta, GA 30006-0026
Meet Philips at the Internet
http://www.usasupport.philips.com





Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V.

Printed in China

English FUNCTIONAL OVERVIEW
Main unit controls (see figure 1)
1 SETUP / RETURN Enter the SETUP menu. Work as return key in PBC disc.

QUICK START UP
4 Volume control (▲ / ▼)
• During playback, briefly press or keep pressing ▲ / ▼ to increase or decrease the sound volume.



OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



INTRODUCTION
Digital video
DVD-Video uses state-of-the-art MPEG2 data compression technology to register an entire movie on a single 5-inch disc.

ADVANCED FUNCTIONS
Setup
To maximize your playback experience, use SETUP to fine tune your settings.



OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



INTRODUCTION
Placement
• Place the player on a firm, flat surface.
• Keep away from domestic heating equipment and direct sunlight.

ADVANCED FUNCTIONS
Video Setup
AV Out Set video output format to TV system.
Screen Display Set screen viewing ratio.



OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



GENERAL INFORMATION
Power Sources
This unit operates on a supplied AC adapter, car adaptor, or a rechargeable battery pack.

ADVANCED FUNCTIONS
Video Setup
AV Out Set video output format to TV system.
Screen Display Set screen viewing ratio.



OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



GENERAL INFORMATION
Handling discs
• Do not attach paper or tape to the disc.
• Keep the disc away from direct sunlight or heat sources.

ADVANCED FUNCTIONS
Video Setup
AV Out Set video output format to TV system.
Screen Display Set screen viewing ratio.


OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



PREPARATIONS
Charging the DVD player
1 Install the battery pack. Plug in the battery pack onto the back of the DVD set.

ADVANCED FUNCTIONS
Video Setup
AV Out Set video output format to TV system.
Screen Display Set screen viewing ratio.


OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



PREPARATIONS
Connection
1 Headphones
Connect the headphones into the jack.

ADVANCED FUNCTIONS
Video Setup
AV Out Set video output format to TV system.
Screen Display Set screen viewing ratio.


OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



QUICK START UP
Basic function of play back
1 Insert the DVD disc
Slide the OPEN switch to open the disc compartment.

ADVANCED FUNCTIONS
Video Setup
AV Out Set video output format to TV system.
Screen Display Set screen viewing ratio.

OSD OPERATIONS
Zoom (JPEG disc)
1 Press OSD repeatedly to select ZOOM.
2 In zoom option, press ▲ / ▼ to move the picture.



IMPORTANT SAFETY INSTRUCTIONS

- 1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings.
8. Do not install near any heat sources.
9. Do not defeat the safety purpose of the polarized or grounding-type plug.

CONSIGNES DE SÉCURITÉ IMPORTANTES

- 1. Lisez ces instructions.
2. Conservez ces instructions.
3. Respectez les avertissements.
4. Suivez toutes les instructions.
5. N'utilisez pas cet appareil à proximité d'une source d'eau.
6. Nettoyez l'appareil uniquement avec un chiffon sec.
7. N'obstruez aucun orifice de ventilation.
8. N'installez pas l'appareil près d'une source de chaleur.
9. Ne détruisez pas la polarisée fournie.

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

- 1. Lea estas instrucciones.
2. Coloque el equipo exclusivamente sobre aquellos carros, bases, tripodes, soportes o mesas especificados por el fabricante.
3. Conserve estas instrucciones.
4. Lea todas las avisos.
5. Siga todas las instrucciones.
6. Para limpiar el aparato utilice sólo un trapo seco.
7. Desenchufe el aparato durante tormentas eléctricas o cuando no vaya a ser utilizado durante largo tiempo.
8. Confíe el mantenimiento y las reparaciones a personal técnico especializado.

PHILIPS LIMITED WARRANTY ONE (1) YEAR

WARRANTY COVERAGE
PHILIPS warranty coverage is limited to the terms set forth below.
WHO IS COVERED:
Philips warrants the product to the original purchaser or the person receiving the product as a gift.

GARRANTIA LIMITADA PHILIPS UN (1) AÑO

COBERTURA DE GARANTÍA:
La obligación de la garantía de Philips se limita a los términos establecidos a continuación.
¿QUIÉNES ESTÁN CUBIERTOS?
Philips garantiza el producto al comprador original o a la persona que recibe el producto como regalo.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>