

4 head mono VCR

VR415

The 400 series: The Longplay VCR

- **Digital Studio Picture Control** – obtain the best possible picture quality regardless of the tape you use
- **Smart Picture** for an individual picture preference setting
- **Turbo Timer** – fast and easy 3-step timer programming. No need to switch on the TV-set.
- **Dirty Head Warning** – the VCR will ask to clean the heads even before you recognise loss in picture quality
- **Automatic Longplay Recording** – never miss the end of a show
- **Multibrand TV Remote Control**

**TURBO
DRIVE**

**DIGITAL
STUDIO
PICTURE
CONTROL**

**Smart
Spicture**

**TURBO
TIMER**



Let's make things better.



PHILIPS

Download from www.Somanuals.com. All Manuals Search And Download.

Product Information

Reception

- Tuner: UHF + VHF + Hyperband
- Tuner System: M
- Tuning: FST, 181 Channel
- Tuning/Install Features: Auto Channel preset, Manual Search/Store
- Sound System Off Air: Mono

Video System

- Video Systems: NTSC 3.58
- Picture Improvement System: DSPC, SMART Picture

Sound System

- Audio Recording System: Linear
- Audio Recording Level: Automatic

User Interface

- OSD Menu Language: English
- Tape Position Indicator: yes
- Special Features: Child Lock

Remote Control Unit

- Remote Control type: 2.2M
- Remote Control codes: TV/CBL/DBS Multibrand, VCR-RC5
- Alternate Channel button: yes

Programming

- Number of Events: 8/year
- Programming Mode: Quick Programming, Turbo Timer
- Record Speed: Standard Play (SP), Long Play (LP), Super Long Play (SLP)

Tape Deck

- Number of (S-)VHS Video / FM Audio / Flying Erase Heads: 4/-/-
- Play: -1, +1, repeat
- Additional Playback Features: Still, Fast Search Speed, Slow Motion
- Repeat Play: 100 times
- Index Related Functions: Next/Previous index search
- Record End Search: yes
- Tape Counter: Real Time Counter, Time Left
- Automatic Functions: Auto Play, Auto Rewind, Auto Eject
- Winding / Rewinding Time: 100 sec
- Head Cleaning Mode: Automatic
- Dirty Head Warning: yes

Connectors Rear

- Video in/out: RCA/RCA
- Audio in/out: mono, RCA/RCA
- Terrestrial Antenna In & Out: 75 Ohm

Connectors Front

- Audio/Video Conn. Front: RCA/RCA

General

- Power Voltage: 110-220V, 60Hz
- Backup Presets & Timer Events: 6 Months
- Backup Clock: Li Battery
- Power Cons. in Play / Std-By: 12.3/3.6
- Equipment Supplied: Remote Control, Batteries, Aerial Cable
- Weight incl. / excl. package in kg: 3.2/4.2
- Set Size - W x D x H (mm): 360x265x94
- Packaging - W x D x H (mm): 458x357x163

Color

- Front, side panels: Silver
- Cover: Silver

4 head mono VCR

VR415

Product Highlights

• Digital Studio Picture Control

Digital Studio Picture Control keeps checking the quality of your videotapes and reproduces the best possible picture performance. Philips' Digital Studio Picture Control optimises the record and the playback quality. It measures the characteristics of the tape, adapts the record characteristics/resolution and reduces the picture noise.

• SMART Picture

With this unique feature, you can adapt the picture to your own preference: you can enhance the contours on a cartoon or suppress the noise from a rental tape. We offer you the possibility to play your tapes the way you like to see them.

• Turbo Timer

Is Timer Programming complicated? No!

Is Timer Programming time consuming? No!

Just push the Turbo Timer button on the remote control and follow the Mini Guide on the rear side of your Remote Control. The display of your VCR asks you for the start and end time as well as the channel number. That's it. Just a number of seconds.

• Multibrand Remote Control

Your Remote Control can control not only your VCR but also your TV and your SAT/DBS box. You can select from a large variety of supported brands.

• Turbo Drive

Turbo Drive is not only a synonym for winding and rewinding at very high speed. It also stands for other high performance Deck features. The built-in Head Cleaner removes dirt from the video heads each time you put in a cassette. The new Dirty Head Warning feature will display a message on the TV screen whenever it is recommended to use a cleaning tape to overcome severe dirt coating. In addition there's a Tape Position Indicator, which shows on your TV screen the progress of winding and rewinding of the tape in real time.

Subject to modification without notice

Let's make things better.



PHILIPS

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>