




# myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for PHILIPS 42PF9631D. You'll find the answers to all your questions on the PHILIPS 42PF9631D in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual PHILIPS 42PF9631D**  
**User guide PHILIPS 42PF9631D**  
**Operating instructions PHILIPS 42PF9631D**  
**Instructions for use PHILIPS 42PF9631D**  
**Instruction manual PHILIPS 42PF9631D**



[Your user manual](#)  
[PHILIPS 42PF9631D](#)

**Manual abstract:**

Mount the 4 spacers and screws as shown in step 2 to gain space between the VESA bracket and the TV's backcover. This will create space for your cables. 50" MAINS MAINS 42" You have 3 options to receive HD programming. 1. Digital Satellite HDTV programming To receive HD programming via satellite, you need an HD satellite receiver and satellite dish. Contact your Satellite TV provider for more information on HDTV service. 2. Cable Subscribe to HDTV programming through your local cable company. You will need a HDTV cable box from them. The cable provider may install the cable and cable box for you. They request certain fees and installation requirements. Please call your cable company for more information. 3. Free Over-the-Air (OTA) broadcast digital HDTV programming This Integrated HDTV has the digital tuner built into the TV set. It does not need a separate set-top box to receive free Over-the-Air digital TV signals (ATSC), since you can receive HD signals via antenna.

For help choosing the right antenna, log onto [www.philips.com/hdtv](http://www.philips.com/hdtv) for more information. 600 8 200 The TV must be switched off when you connect. For more connections and hook up options, turn the page.

Manual del usuario Consulte el manual del usuario en el kit de usuario incluido con el televisor. Manual do Usuário Consulte o Manual do Usuário do Kit do Usuário fornecido com o seu televisor. Ayuda en línea [www.philips.com/support](http://www.philips.com/support) Ajuda on-line [www.philips.com/support](http://www.philips.com/support) Línea de contacto 1 45442047 (Argentina) Tenga el número de modelo y número de serie cerca cuando llame. Encontrará estos números en la etiqueta de embalaje o en la parte posterior e inferior del televisor. Telefone de contato 55 800 701 02 03 (Brasil) Tenha o Modelo e o Número de série à mão antes de telefonar. Pode encontrar estes números na etiqueta da embalagem ou na parte traseira e inferior do televisor.

x4 Achteraan uw TV vindt u de 4 VESA schroefgaten. Monteer de 4 afstandstukjes en bouten zoals in tekening 2 om plaats te maken tussen de VESA wandsteun en de TV. Hiermee ontstaat er ruimte voor de uw aansluitingskabels. VESA, FDMI and the VESA Mounting Compliant logo are trademarks of the Video Electronics Standards Association. Need Help ? . needs no translation. Only French ici Only Eng & French ici The TV must be switched off when you connect. 4 The remote control La télécommande Mando a distancia Telecomando Cable or Satellite set top box VCR USB / Headphone / Camera / Games Record ANTENNA CABLE TO TV HDTV HDTV capable connections HDTV programming from a HDTV cable box or satellite receiver need the HDMI or Component Video Input (RGB) depending on the output available on the HDTV cable box. S-Video or standard Composite Audio/Video cannot pass HDTV signals. USB S VIDEO & AUDIO Record S-Video ANTENNA CABLE TO TV & AUDIO VIDEO IN OUT HDMI HDMI ANTENNA CABLE TO TV IN OUT IN OUT AV S VIDEO VIDEO R AUDIO L Pr /R Pb /B Y /G L AUDIO R Record Record USB Certain digital cameras or USB devices which require driver software are not supported by the USB connection.

R AUDIO Y ANTENNA HDMI 1 HDMI 2 ANTENNA L S VIDEO AUDIO R Pb HDMI 2 ANTENNA L VIDEO AV 2 5 Switch on Press the power switch at the left of the TV. POWER POWER POWER POWER In the TV menu, assign this DIGITAL AUDIO IN to the AV1 input. TV Menu : Settings ] Setup ] Source ] Digital Audio In In the TV menu, assign this DIGITAL AUDIO IN to the AV1 input. TV Menu : Settings ] Setup ] Source ] Digital Audio In In the TV menu, assign this DIGITAL AUDIO IN to the AV1 input. TV Menu : Settings ] Setup ] Source ] Digital Audio In In the TV menu, assign this DIGITAL AUDIO IN to the AV1 input.



[Your user manual](#)  
[PHILIPS 42PF9631D](#)

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>