

Juice Extractor

MODEL PJE020



USER GUIDE WITH RECIPES

Visit our web site at: www.buyprima.com

IMPORTANT SAFEGUARDS

- 1. Please read through the information and safety advice contained in these operating instructions carefully and thoroughly before you use the Juicer for the first time.
- 2. Place Juice Extractor on a flat, stable, cool work surface.
- 3. Never allow children to operate this appliance.
- 4. Make sure that the voltage shown on the rating plate corresponds with that of the mains supply. The rating plate can be found on the bottom of the motor block. The product is only to be connected to an AC supply (~). The motor must always be switched off before the product is connected to the main supply. ('0' setting).
- 5. This Juicer has a safety switch and only operates when the two black handles are locked into place.
- 6. Do not use the Juice extractor continually for more than one minute at a time. If the machine becomes too hot then it will automatically shut down until the motor is cool enough to start up again. Once it has shut down the machine normally takes about 15 minutes to cool down before it can be used again.
- 7. If the supply cord is damaged, its must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard. Do not attempt to repair the device yourself.
- 8. Do not immerse the unit in water or any other liquid. Simply wipe with soft damp cloth.
- 9. Close adult supervision is necessary when using this or any appliance where children are present.
- 10. Never leave the appliance connected to the mains and unattended.
- 11. Avoid contacting moving parts. Always use the Juicer stick to feed fruit into the feeding tube NEVER use fingers.
- 12. Do not use any attachments other than those supplied. To do so would invalidate your warranty.
- 13. Do not let the cord hang over the edge or counter top.
- 14. Never interfere with or try to bypass the safety switches.
- 15. Make sure when removing parts to clean the power is switched off and unplugged from the wall socket.
- 16. Do not use out doors.
- 17. Please note that this appliance is for domestic use only.

Technical Information

Voltage/frequency: 230V~50Hz (600W)

Juice capacity: 1 litre Pulp capacity: 2 litres

Parts and Assembly




IMPORTANT

THE JUICE EXTRACTOR IS EQUIPPED WITH A SAFETY INTERLOCK SWITCH. THIS IS FITTED TO PREVENT THE MOTOR FROM BEING ACTIVATED WHILE THE MACHINE IS DISASSEMBLED. THE MOTOR WILL NOT RUN UNLESS THE REMOVABLE TRANSPARENT COVER IS ON SECURELY AND LOCKED INTO PLACE WITH THE SAFETY LOCKING HANDLES.

ASSEMBLY

Before first use it is a good idea to familiarise yourself with the assembly/disassembly of the unit.



- 1. Juicer Stick
- 2. Transparent Cover
- 3. Filter net
- 4. Residue Container
- 5. Locker
- 6. Rotor
- 7. Pulp Container
- 8. Switch
- 9. Main Body
- 10. JuiceContainer

ASSEMBLY

- 1. The appliance should be unplugged from the mains before assembly or disassembly.
- 2. Place the pulp container under the nozzle on the left of the machine. Place the juice container under the nozzle on the right of the machine.
- 3. Attach the residue container onto the main body and clip the filter net into place.
- 4. Attach the top transparent cover and close and place the juicer stick in the food chute.
- 5. Make sure the housing unit is locked with the safety lockers in place by hooking them onto the top cover and pushing them downwards until they clip in place.
- **6.** The juicer will not work for safety reasons if the safety lockers are not locked in place correctly.

DISASSEMBLY

- 1. Remove the juicer stick and the pulp and juice containers.
- 2. To remove the upper body pull both safety lockers outwards from the bottom. Release and lift off the top cover.
- 3. Lift the filter net off by gently pulling upwards.
- 4. Lift of the Residue container.

SETTINGS

There are 2 settings 1 and 2

Setting 1 is low speed and is usually best for soft fruits such as plums and peaches (Please remove the stone before trying to juice!)

Setting 2 is faster and is usually best for harder fruits such as apples and carrots.

PLEASE NOTE: There is a temperature safety device installed in the machine. If the machine becomes too warm the machine will automatically shut down until the motor has cooled to the correct temperature. (This usually takes about 15 minutes). To prevent this from happening please do not use the machine continually for more than one minute at a time.

Juicing

- 1. Assemble the machine as described above.
- 2. Connect to mains supply.
- 3. Remove the Juicer Stick (it simply lifts out).
- 4. Ensure the juicer and pulp containers are in place.
- 5. Start the machine using the power switch and turning it to position 1 for slow and position 2 for fast.
- 6. Slowly add the fruit/vegetable pieces via the food chute using the Juicer Stick to feed the fruit down the chute. Please remember to remove any large stones in fruit or any peel that you would not normally eat.
- 7. The juicer is efficient but do not to over load the machine by feeding too much through at once.
- 8. Once the juice container is full you can empty the juice into another container and then resume juicing.
- 9. Once the Pulp container is full, switch of the juicer at the mains supply and disassemble as described above. Empty the sediment from the sediment container and re-assemble as described above. Switch on the mains supply, you can now continue juicing.
- 10. Notes: The amount of juice produced depends upon the type of fruit/vegetable used and how ripe it is. Only put through things that you would normally eat, for example; Kiwi fruit should be peeled first. Never put sharp objects down the food chute.

Please note that bananas are not suitable for juice extractors due to the way the fruit is structured.

Cleaning

When cleaning this product please observe the following precautions:

- Always ensure the unit is switched off & unplugged from the mains
- Disassemble as described in the disassembly instructions.

All parts except the Main Body (9) can be washed with warm soapy water, rinsed and dried thoroughly.

To clean the Main Body (9) wipe with a soft damp cloth. DO NOT IMMERSE IN WATER OR PLACE IN THE DISHWASHER. THE MAIN BODY CONTAINS THE ELECTRICAL COMPONENTS.

Useful Tips

- 1. Gently feed the fruit through the fruit shoot one by one. DO not try and over cram food into the juicer.
- 2. If you are processing solid ingredients, cut them into small pieces (2-3cm) first.

Recipes

Easy Drinks – simply put the ingredients through the juicer in the stated order and enjoy!

Carrot, Apple and Ginger

6 carrots Slice of root ginger 2 apples

Apple and Pears

2 apples 2 pears

Apple and Grapes

2 apples I large bunch grapes

Waldorf

3 apples 1 celery stick

Apple and Strawberry

2 apples 100g strawberries

Strawberry Punch

2 large oranges 100g strawberries 100ml cranberry juice Ice

- 1. Put the strawberries and oranges through the juicer.
- 2. Mix in the cranberry juice and add ice.

Orange and Blueberry Punch

2 large oranges 100g blueberries Ice

1. Juice together in the given order.

Pireapple and Apple Cocktail

½ anneapple

1. Juice together in the given order

Pineapple Cocktail

½ pineapple 2 apples

1. Juice together in the given order.

Pink Cocktail

½ pineapple 100ml cranberries ½ lemon

- 1. Juice together the pineapple and cranberries
- 2. Serve and add a squeeze of lemon juice to taste

Sweet Potato and Grapefruit

2 pears

2 pink grapefruit

1 sweet potato

1. Juice together in the given order

Apple, Pear and Lime

2 apples

2 pears

½ lime

- 1. Juice together the apples and pears.
- 2. Serve and add a squeeze of lime juice to taste

Rich Tomato Cocktail

6 tomatoes

1 beetroot

1 slice lemon

- 1. Juice together the tomatoes and beetroot
- 2. Serve and add a squeeze of lemon juice to taste

Spicy Tomato

4 ripe tomatoes

1 celery stick

1/400 pepper
1 slice onion
1 clove garlic
5ml Worcestershire sauce
1 pinch ground black pepper
Hot chilli sauce (use as desired)

- 1. Juice together the tomatoes, red pepper, celery stick, apple, onion and garlic.
- 2. Mix together and add the Worcestershire sauce, pepper and chilli sauce.

Vege Cocktail

- 1 beetroot
- 1 sweet potato
- 2 apples
- 1 lemon
- 1 tomato
- 1 slice onion
- 1 garlic clove
- 250ml apple juice
- 1. Juice together the beetroot, sweet potato, apples, tomato, onion and garlic clove.
- 2. Mix together and add the apple juice and lemon juice.

PLEASE NOTE: All these recipes are only guidelines, please feel free to experiment.

There are many good recipe books available from most bookshops on Juice extractors and recipes for them.

Plug Wiring

The wires in the mains lead are coloured in accordance with the following code:


BROWN - LIVE (L)
BLUE - NEUTRAL (N)

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

- The BLUE wire is the NEUTRAL and must be connected to the terminal which is marked with the letter N or coloured BLACK
- The BROWN wire is the LIVE and must be connected to the terminal, which is marked with the letter L
 or coloured RED.

Always ensure that the cord grip is positioned and securely fastened.

WARNING: ON NO ACCOUNT MUST EITHER THE LIVE OR NEUTRAL WIRES BE CONNECTED TO THE EARTH TERMINAL



~~~~ Warranty ~~~~

This product is guaranteed for 12 months from the date of purchase when the appliance is used solely for domestic purposes. For commercial use the product is guaranteed for 90 days from the date of purchase.

The guarantee is valid against mechanical or electrical defects if the product is used in accordance with the instructions and provided that it is not connected to an unsuitable electricity supply or dismantled, interfered with or damaged in any way.

IMPORTANT, PLEASE RETAIN THIS WARRANTY

Please ask your retailer to either stamp this warranty or simply attach your store receipt. Keep this warranty somewhere safe. DO NOT SEND TO PRIMA.

This guarantee in no way affects your rights under statutory law.

IF THE PRODUCT MALFUNCTIONS DURING ITS WARRANTY PERIOD IT MUST BE RETURNED TO THE RETAILER FROM WHOM IT WAS PURCHASED FOR REPLACEMENT. IF YOU BOUGHT THIS PRODUCT VIA MAIL ORDER, PLEASE KEEP ALL THE DOCUMENTATION THAT CAME WHEN THE UNIT WAS DELIVERED.

NAME	·
ADDRESS	
PURCHASED FROM	
DATE OF PURCHASE	_MODEL
© Convright 2006 Nu-World LIK Ltd. All rights reserved	

Nu-World UK Ltd, Prima House, 15 (2D) Springfield Commercial Centre, Bagley Lane, Leeds. LS28 5LY. UK

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com