### **RadioShack**





www.radioshack.com





You can assemble up to four different vehicles - a plane, helicopter, submarine, or a racecar! The transmitter controls vehicle movement from up to 50 feet away, and you can reach driving speeds of up to 45 feet per minute. Your vehicle comes in two frequencies (27 MHz and 49 MHz), so you and your friends can play together. Check the box to see which frequency you have. This toy is suitable for children ages 3 and up.

### transmitter parts inventory 2. Replace the cover, securing it with the screw. In the vehicle 1. Rotate ON/OFF to OFF. 2. Remove the battery compartment cover and insert four AA batteries. 3. Replace the cover, securing it with the screws. driving your vehicle Hold the transmitter straight up and Thank you for purchasing your 4-in-1 as high as possible. Rotate ON/OFF Puzzle Vehicle from RadioShack. on the vehicle to ON. Hold down to drive your vehicle forward. what's included Release both buttons to brake and stop. Hold down to drive in reverse (backward) and circle backwards. 15 vehicle parts transmitter Please read this user's guide before installing, setting up and using your new product

Download from Www.Somanuals.com. All Manuals Search And Download.


installing batteries

You will need four AA batteries to power your vehicle, and one 9-volt battery to power the transmitter (neither supplied).

## In the transmitter

1. Remove the battery compartment cover and insert a 9V battery.





©2004. RadioShack Corporation. All rights reserved. RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

60-2809 04A04 Printed in China



• Use only fresh batteries of the required size

helpful hints

time can generate high heat levels, resulting

· Running your vehicle for long periods of

in wear and tear on the motor. When the

battery power dies in your vehicle, let the

• If the motor runs, but the vehicle does

not respond to the transmitter, move the

transmitter closer to the vehicle and try

• If someone is using a CB nearby, it may

• You cannot operate your vehicle near

Dispose of old batteries promptly and

cause interference. Move your vehicle away

devices with transmitters that use the same

the batteries.

from the CB.

properly.

frequency (27/49 MHz).

• Do not burn or bury batteries.

and recommended type.

again.

vehicle cool for 10 minutes before replacing

• If you do not plan to use the vehicle for a week or more, remove the batteries. Batteries can leak chemicals that can damage electronic parts.

## The FCC Wants You to Know

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local RadioShack store or an experienced radio/TV technician for help.
- If you cannot eliminate the interference, the FCC requires that you stop using your vehicle.
- Changes or modifications not expressly approved by RadioShack may cause interference and void the user's authority to operate the equipment.

# limited 90-day warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. For complete warranty details and exclusions, check with your local RadioShack store.

RadioShack Customer Relations 200 Taylor Street, 6th Floor, Fort Worth, TX 76102 04/04

Download from Www.Somanuals.com. All Manuals Search And Download.

**RadioShack** 

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com