

Handheld Radio Scanner

Start Here

See the User's Guide for complete instructions.

Package contents



Scanner



Antenna



Rechargeable Battery Holder




Alkaline Battery Holder



Belt Clip




User's Guide



Quick Start


① Install batteries



Rechargeable batteries

Alkaline batteries

② Install antenna



③ Find and store frequencies

1. Press . The service search starts in two seconds.
2. Press **ENT** when you find an interesting frequency (not applicable for marine or weather service banks). The bank number and **StorE** appear.
3. If you want to change storage banks, enter the new bank number.
4. Press **ENT** to store the frequency. The channel and frequency flash twice. To cancel the operation, press **TUNE/CLEAR**.

Program known frequencies

Refer to www.radioreference.com for a list of frequencies in your area.

1. Press **PGM**. **PGM** appears. Enter the channel number (1–200) where you want to store a frequency, then press **PGM** again.
2. Use the number keys and **•** to enter the frequency.
3. Press **ENT** to store the frequency into the channel.
4. Press **SCAN** to begin scanning stored/programmed frequencies.



PGM (Program)

ENT (Enter)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>