




To Automatically Steer to a Fixed Wind Angle




Autotack



Auto Tack
PORT



Auto Tack
STARBOARD



N.B. Refer to section 1.5 of the
ST7002 Operating Guide for full details.


To Adjust Autopilot Course-keeping Accuracy

Autopilot response controls course-keeping accuracy. Higher response settings keep a tighter course but increase the amount of drive activity and battery use. Set to a level appropriate for your needs



Use ▼ or ▲ to adjust response level.
Press **disp** to return to previous mode.


To Adjust Lighting Level



Use **disp** to adjust lighting level.
Wait 10 sec to return to previous mode.


Raymarine®

SmartPilot® ST7002 Controller






Quick Start Guide


Display Layout







To change the Autopilot Heading






x3






To follow a Route set on a Chartplotter



To activate the Autopilot



For Manual Control



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>